

SP™ Series AC Brushless Servodrive Manual

Revision 3.1 (6/99)
P/N MNLSP-3.1



Solutions in Motion

UltraDrive / Westamp
9006 Fullbright Avenue
Chatsworth, CA 91311
Phone: (818) 709-5000
Fax: (818) 709-8395
e-mail: info@westamp.com
Web: <http://www.westamp.com>

Copyright 1997 - 1999 UltraDrive / Westamp
All rights reserved. Specifications subject
to change without notice

TABLE OF CONTENTS

Table of Contents	ii
Product Warranty	1
Foreword	2
Manual Organization.....	2
Typographical Conventions.....	2
System Components and Options	3
SP Series Power/Drive Modules.....	3
Key Components	3
Connections for the 230 VAC Series SP (97 to 265VAC).....	5
Adjustments.....	5
Fault Indicator Board.....	6
SP Series Personality Modules	7
Adjustments.....	7
Servodrive Replacement	7
Load-to-Motor Inertia Mismatches	8
User - Configurable Jumpers	10
Personality Module Jumpers	10
J1 Limit / Enable Jumpers	11
Fast Power-Up Jumper	11
Control Board Jumpers.....	12
Control I/O Connector J11	13
Control I/O Cable	13
Shunt Regulators	14
What is it?	14
You need a shunt regulator if.....	15
Shunt Regulator Specifications	15
Alternatives to Shunt Regulators.....	16
Using a Shunt Regulator	17
Possible Servodrive Configurations	18
Multi-axis System Sharing Power Supply.....	18
Sharing Shunt Regulators	19
Using the SP as a DC Servodrive.....	20
Using the New SP Servodrive in Place of the Earlier Version.....	21
Getting Started.....	24
Mounting Instructions.....	24
Making Servodrive Connections.....	26
Input Power.....	26
Input Power Filtering.....	30
Motor Feedback and Power Connections.....	32
Input Command Signals and I/O	38

Motor Temperature Fault Configuration	42
Making Positioning Module Connections	43
Feedback	43
Using an External Power Supply for the Encoder.....	44
Before Applying Power.....	45
Initial Adjustments.....	45
Decouple the Motor	45
Applying Power	46
Moving the Motor	46
Tuning	48
With no Internal Positioning Module.....	48
Servodrive Connection Definitions and Specifications.....	52
J1- Input / Output commands.....	52
J2 -Feedback Connector.....	55
TB401 - AC Input Voltage	56
TB402 - Servodrive Output (Motor) Terminals.....	56
TB403 - Shunt / DC Power Terminals.....	56
TB404 - Control Input Voltage (SP150 and above).....	56
J11 -Control I/O Connector	57
J11 - Pins 12 to 15: Fault Bit Status Chart	58
Connectors and Configuration Jumpers	59
Control Board Jumpers	59
Personality Module Jumpers	59
Troubleshooting Guide.....	61
Fault Indications	61
Troubleshooting Procedures.....	63
Drawings.....	69

PRODUCT WARRANTY

Westamp Incorporated, hereafter referred to as "Seller", warrants that the article delivered will be free from defects in material and workmanship under normal use and service. The Seller's obligations under this warranty are limited to replacing or repairing, at the Seller's option, any of said articles which shall within two (2) years after shipment be returned to the Seller's factory of origin, transportation charges prepaid, and which are, after examination by the Seller, disclosed to the Seller's satisfaction to be thus defective.

THIS WARRANTY IS EXPRESSED IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING THE IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE AND OF ALL OTHER OBLIGATIONS OR LIABILITIES ON THE SELLER'S PART, AND THE SELLER NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON OR ORGANIZATION TO ASSUME FOR THE SELLER ANY OTHER LIABILITIES IN CONNECTION WITH THE SALE OF THE SAID ARTICLES.

This warranty shall not apply to any such articles which have been repaired or altered, except by Seller, or which have been subject to misuse, negligence or accident. The aforementioned provisions do not extend the original warranty period of any article which has been repaired or replaced by the Seller.

Manual Organization

This manual is organized in such a manner to present the relevant and necessary information in an order that will allow the user to get up and running quickly. By reviewing the information chapter by chapter in the order presented, the user is provided with important information in a logical manner.

This chapter, for example, provides information necessary to understand all of the options and configurations available with your SP series servodrive system.

Typographical Conventions



THIS SYMBOL REPRESENTS A CAUTION THAT WARNS OF POSSIBLE INJURY OR DEATH TO PERSONNEL OR DAMAGE TO MACHINERY. WHENEVER THIS SYMBOL IS PRESENT IN THIS MANUAL, IT IS EXTREMELY IMPORTANT THAT THE TEXT ASSOCIATED WITH THE SYMBOL IS COMPLETELY READ AND UNDERSTOOD. THIS WILL HELP AVOID PERSONAL INJURY, DEATH AND/OR DAMAGE TO MACHINES.



This symbol represents a caution that warns of possible damage to the servodrive or machinery. Whenever this symbol is present in this manual, it is extremely important that the text associated with the symbol is completely read and understood. This will help avoid damage to the servodrives, motors and machinery.

SYSTEM COMPONENTS AND OPTIONS

This chapter provides an overview of all of the system configurations and options that make up the SP series servodrive.

SP Series Power/Drive Modules


Key Components

The SP series Power/Drive Modules are the heart of your servo system. Each module consists of the following key elements (refer to picture on next page):

1. Control/Drive Electronics - This is the heart of the motor controller and includes all electronics for controlling and driving the servomotor in either the torque or velocity modes.
2. Output Power IGBT Transistor - This component is controlled by the Control/Drive Electronics to drive the motor with the appropriate current and voltage.
3. Input Power Electronics (Optional) - This section rectifies the single or three phase AC input supplied to the Power/Drive module. Some of the electronics on this board include bus capacitors, phase loss detection and soft-start control.
4. Logic Power Supply Electronics - This component provides the Control/Drive Electronics with the control voltages necessary to operate. Additionally, it supplies the optional Positioning Module with control voltages.
5. Positioning Module (Optional) - This optional card provides for the closure of a position loop. Additionally, the positioning module can close a digital velocity loop that includes acceleration feed-forward capabilities.
6. Control I/O Connector - Servodrive Signal Input, Encoder Outputs, Fault Outputs, and a servodrive Reset / Disable input are supplied through the J11 Connector. This eases the requirements of connecting the servodrive to an external motion card by supplying the needed servodrive I/O on a single high density, 15 pin connector.
7. Diagnostics - provides LED fault indications for Encoder

Signal Loss, Motor Ground, Overcurrent (Surge), RMS current, Bus phase loss, Bus over voltage, Overtemperature (motor and servodrive), and Logic Voltage Failure.

8. Personality Module - Provides for all user configurable, motor and load specific configuration and compensation components. Also provides all user and application specific adjustments. Note that in the unlikely event a servodrive should need replacement in the field, the personality module can be removed from the old drive and placed in the new drive. No adjustments are necessary as all previous adjustments are retained on the personality modules.



Connections for the 230 VAC Series SP (97 to 265VAC)

The 230 VAC Input Series products are indicated by the "2" in the part number. For example, SPXXX-2-XX-X indicates a 230 VAC series product. These products have an input voltage range from 97 to 265 VAC. Note that the motor's achievable top speed is directly related to the AC input voltage. All SP Series speed versus torque curves were generated based on a 240 VAC, three phase main. Lower than published top speeds can be expected with input voltage mains below 240 VAC or use of single phase power.

Input Power Connector	TB401
Motor Output Power Connector	TB402
DC Power Input/Shunt Connector	TB403
Special Single Phase Input (Only for SP150 and up)	TB404
Servodrive Input Commands Connector	J1
Motor Feedback Connector	J2
Control I/O Connector	J11

Adjustments

There are no user adjustments on the Power/Drive Module. All adjustments are made on the Personality Module housed in the Power/Drive Module.

There are, however, configuration jumpers that may need to be considered in certain circumstances. If you are using a Westamp BR Series Brushless Servomotor and Westamp cabling, the standard factory settings for these configuration jumpers are optimum.

If, however, you are using a different motor or cabling, a review of the section entitled *Connectors and Configuration Jumpers* is suggested.

Fault Indicator Board

The Fault Indicator Board provides individual fault indications for all servodrive faults. In addition, a RESET push-button is provided to reset the servodrive manually after a servodrive fault has been cleared. The Fault Indicator Board is an integral part of the SP series servodrive and should not be removed.

The following LED Indications and their descriptions are listed below. For a detailed description of possible causes, refer to Trouble Shooting Guide, Fault Indications.

Fault Condition	LED #	DESCRIPTION
ENC FAULT	CR15	Encoder Fault - Loss of an encoder signal. JP-15 on the control board must be removed to allow an Encoder Fault to create a latched fault condition. See J2 - Feedback Connector Encoder Fault, and Control Board Jumper definitions (JP-15) and specifications.
RMS	CR9	RMS current has exceeded the servodrive's rating.
SURGE	CR10	Surge over currents from the servodrive output, usually caused by a short circuit in the output leads.
GROUND	CR11	Motor Ground Fault - Senses non-returning servodrive output currents, usually caused by a servodrive output lead being shorted to ground.
LOGIC	CR12	1- The sum of the + and - 12V has dropped below 22V. 2- The 5V source has dropped below 4.5V.
TEMP	CR13	1- Excessive servodrive heat sink temperature. 2- Excessive motor temperature. JP-3 on the personality module must be removed to allow a Motor Temperature Fault to create a latched fault condition. See J2 - Feedback Connector Motor Temp Fault, and User Configurable Jumpers, Personality Module Jumpers.
BUS/PHASE	CR14	1- Excessive regenerative energy from a decelerating load. 2- One of the phases of the 3 phase AC input has failed.

SP Series Personality Modules

Personality Modules in the SP Series house all user-configurable, motor-specific and load-dependent configuration and compensation components. There are two types of personality modules available: Adjustable and Fixed compensation.

Adjustments

The adjustable compensation "A" modules include adjustments for the following:

CMD adjustment	CoMmanD signal input DC gain
Tach adjustment	TACHometer feedback DC gain
C-Comp adjustment	Coarse Compensation -- Velocity loop AC gain
F-Comp adjustment	Fine Compensation -- Velocity loop AC gain
I-Limit adjustment	Current Limit -- Clamps peak output current of servodrive
Offset	Nulls input offsets up to 50 millivolts

For fixed compensation personality modules, only the **Offset** adjustment is present.

Servodrive Replacement

In the event a servodrive should need replacement in the field, the personality module can be removed from the old drive and placed in the new drive. No adjustments are necessary, as all previous adjustments are retained on the personality modules.

This eliminates the need to send a field service technician to the customer's site to install the replacement servodrive.

Load-to-Motor Inertia Mismatches

With low-inertia, high-performance, brushless servomotors, such as the Westamp BR Series, it is inevitable that the load inertia will often exceed that of the motor driving them. In an ideal world where shafts and couplings have no spring constants (absolute stiffness), this would not be a problem. Since "absolute stiffness" is not a reality, it is indeed a problem.

As the load is accelerated to, or decelerated from speed, the mechanisms between the motor and the load flex. As the motor accelerates, for example, part of the motor's shaft, coupling and the load actually lags behind the accelerating motor. When the motor reaches the desired speed these mechanisms "spring" back and overshoot the desired speed. If the velocity loop in the servodrive has sufficient bandwidth to respond to this overshoot, as seen in the tachometer feedback signal, it will attempt to correct it by driving the motor's speed down. This creates another lag between the motor and the load. This process is repeated over and over again, and instability is the result.

Westamp has provided a means for dealing with this problem. The part number for the Personality Modules includes two (2) digits for specifying inertia mismatches. For example, the "05" in *SP-MPM-XXX05-X* indicates a 5:1 load to motor inertia mismatch. Specifying the inertia mismatch in this manner provides Westamp with minimum application data that, in most cases, is sufficient for us to provide a Personality Module critically damped for your application.

Westamp does this by assuming that the component with the lowest natural resonant frequency is the motor's shaft, and then rolling-off the velocity loop at a frequency lower than this resonance. In most applications, this works exceptionally well. However, there are system components that can undermine this philosophy. If a coupling is used between the motor and load, it is critical that high-grade servo couplings are specified. These couplings are designed to provide high natural resonant frequencies, usually much higher than most other servodrive mechanisms.

What is more important than knowing the inertia mismatch, however, is knowing the frequency of lowest resonance in the drive train. This can be accomplished by using an oscilloscope to observe the tachometer signal on J1, pin 3 with respect to pin 4. This issue will be further discussed in the section entitled *Tuning*, later in this manual.

User - Configurable Jumpers

Personality Module

Jumpers

There are configuration jumpers on the Personality Module to provide flexibility for a wide variety of applications. The following table details these jumpers and their purpose:

Jumper	Function
JP-1	<p>Differential / Single-ended Command Input Jumper - This jumper is used in conjunction with the J1 connector Speed/Torque inputs.</p> <p>For Single-ended Non - Inverted Input: (normal configuration) The JP-1 shorting jumper is placed on positions 2 and 3 (bottom two pins). In this configuration the Speed/Torque / command (J1 pin 1) is grounded. A servodrive input signal command would be applied to the Speed/Torque command J1 pin 2 with respect to ground.</p> <p>For Single-ended Inverted Input : The JP-1 shorting jumper is placed on positions 1 and 2 (the top two pins). In this configuration the Speed/Torque command (J1 pin 2) is grounded. A servodrive input signal command would be applied to the Speed/Torque / command J1 pin 1 with respect to ground.</p> <p>For Differential Input : The JP-1 shorting jumper should be removed. Refer to the J1 connector for explanations on the signal input modes. In this configuration, the input signal would be applied to the differential inputs: Speed/Torque command J1 pin 2 and the Speed/Torque / command J1 pin 1.</p>
JP-2	<p>High / Low Gain Jumper -</p> <p>For velocity control mode: Remove the JP-2 jumper.</p> <p>For torque (current) mode: Install the JP-2 jumper.</p> <p>Normal Westamp Configuration is velocity control mode (JP-2 jumper removed).</p>
JP-3	<p>MTR Temperature Fault Disable. If a servodrive fault / shutdown is NOT desired when a motor over temperature condition occurs, the JP-3 jumper on the Personality Module must be installed. When this jumper is installed, a Motor Temperature Fault condition will be sensed by the MTR Temp Fault Out pins (J1-16 and J1-17), but it will not disable the servodrive. If the JP-3 jumper is not installed, the MTR Temp Fault condition will disable the servodrive, creating a servodrive temperature fault.</p> <p>The Normal Westamp Configuration is JP-3 removed (Motor Temp Fault will cause a servodrive fault).</p>
JP-11	<p>Velocity Loop Integrator Jumper:</p> <p>For highest bandwidth: (lowest value integrator) Install the JP-11 Jumper on pins 1 & 2.</p> <p>For lowest bandwidth: (highest value integrator) Install the JP-11 Jumper on pins 2 & 3.</p> <p>The Normal Westamp Configuration is for lowest bandwidth (JP-11 jumper on pins 2 and 3). Refer to the section on <i>Tuning</i> for more information.</p>
JP-12	<p>Internal Tach Jumper. To use the internal electronically derived tachometer (Normal Westamp Configuration), the JP-12 jumper should be installed.</p> <p>If an external tach is used (refer to J1-3, Command Input connector), or if the servodrive is configured for torque (current) mode, the internal tach may be disabled by removing JP-12.</p>

J1 Limit / Enable Jumpers

The J1 connector has the following pins that must be connected to logic common (J1 pin 27) for proper operation:

J1 Pin#	Function /Description
24	<p>N.C. Neg Limit Input - When this input is at a CMOS logic high, or allowed to float, all negative command inputs to the non-inverted input J1 pin 2 with respect to the inverted input J1 pin 1 are clamped. This input must be forced low for normal operation. Internal pull-ups will hold this pin at a CMOS (12V) logic high if it is allowed to float. Internal diodes allow for voltages of up to 40V to be applied to this pin when in its high state.</p> <p>Note that this input disables all current in one direction only. The Drive Ready will remain asserted (Drive Ready will remain high, Drive Ready / will remain low).</p>
25	<p>N.C. Pos Limit Input - When this input is at a CMOS logic high, or allowed to float, all positive command inputs to the non-inverted input J1 pin 2 with respect to the inverted input J1 pin 1 are clamped. This input must be forced low for normal operation. Internal pull-ups hold the normal condition of this input at a CMOS (12V) logic high if it is allowed to float. Internal diodes allow for voltages of up to 40V to be applied to this pin when in its high state.</p> <p>Note that this input disables all current in one direction only. The Drive Ready will remain asserted. (Drive Ready will remain high, Drive Ready / will remain low).</p>
26	<p>N.C. Disable Input - When this input is at a CMOS logic high ,or allowed to float, all servodrive output will be disabled. This output must be forced low for normal operation. Internal pull-ups will hold this pin at a CMOS (12V) logic high if allowed to float. Internal diodes allow for voltages of up to 40V to be applied to this pin when in its high state.</p> <p>Note that this input disables all output, and will place the servodrive in a “Not Ready” state when it is asserted.</p>
27	Logic common

The factory default is for J1 pins 24, 25 and 26 to be tied to Logic Common (J1 pin 27). This allows for normal operation when the N.C. Enable / Limit jumpers are not desired.

Fast Power-Up Jumper

Without J1 pin 29 and 30 shorted together, the servodrive has a 1 to 2 second startup delay to allow motion controllers and other system components time to stabilize. After the startup delay time, the Drive Ready signal will be asserted (refer to Servodrive Connection Definitions and Specifications). When pins 29 and 30 are shorted together the startup delay is reduced to 100 to 200 milliseconds.

Control Board Jumpers.

For most applications, the jumpers on the control board will not need to be changed. If you are using a Westamp BR Series Brushless Servomotor and Westamp cabling, then the standard factory settings for these configuration jumpers are optimum.

If, however, you are using a different motor or cabling, a review of the section entitled *Connectors and Configuration Jumpers* is suggested.

Control I/O Connector J11

The Control I/O connector brings out the connections needed for a positioning controller to one connector, making multi-axis controller configurations easier to connect. The table below outlines the pin designations for this connector. Refer to J-11 Control I/O connector under *Servodrive Connection Definitions and Specifications* for a complete description and specifications for this connector.

HD15 (P11) Pin#	Function
1	Speed/Torque / (Command Signal) Inverted Input
2	Speed/Torque (Command Signal) Non-Inverted Input
3	Ground
4	Z/ reference
5	Z reference
6	B/ reference
7	B reference
8	A/ reference
9	A reference
10	Servodrive Fault Reset / Disable input
11	Power On output
12	Fault bit 0 output
13	Fault bit 1 output
14	Fault bit 2 output
15	Fault bit 3 output

Control I/O Cable

A High Density cable is available from Westamp for the J11 connector. The cable consists of a matching HD15F connector on one end and stripped, tinned fly leads on the other. The cable is available in 5 and 15 foot lengths. Refer to the drawings section for a cable description drawing.

Length: 5 foot Part # SP-CC-005
 15 foot Part # SP-CC-015

Shunt Regulators

What is it?

A shunt regulator is a dissipative device used to regulate the bus voltage of the servodrive. The bus is the voltage used by the output IGBT transistors to supply voltage and current to the motor. The output IGBT transistors and associated circuitry have safe operating voltage areas that must not be exceeded for reliable operation.

Under certain situations during deceleration of the motor and load, the motor returns a portion of the kinetic energy stored in the rotating load back to the servodrive. Since the input rectifiers on the servodrive will not allow the excessive voltage to be returned to the AC line, the bus voltage, if left uncontrolled, will increase to unsafe levels.

Usually the shunt regulator is a passive device with only minimal power dissipation for control circuits. These control circuits "watch" the bus voltage levels and trigger the shunt IGBT power transistors ON when the levels reach a preset level of approximately 400 VDC on the 230 volt series. The power transistor is in series with high power resistors (often supplied by the customer) that dissipate the regenerative energy in the form of the heat they generate.

You need a shunt regulator if...

There are some "rules of thumb" that can be used to determine if a shunt will be required for a system. These are not absolutes, however.

If your system has one or more of the following characteristics, chances are you will need a shunt regulator:

- ⇒ High inertia mismatch between the motor and the load (load being greater).
- ⇒ High mass load.
- ⇒ Low friction in load.
- ⇒ Vertical motion without the use of a counterbalance system.
- ⇒ Your system does not have a shunt and the servodrive shuts down with a "BUS" fault during deceleration cycle of the motor.

Shunt Regulator Specifications

There are three shunt regulators available for the SP series servodrives. The table below outlines specifications for each.

Part Number	Peak Power (kWatts)	Cont Power (kWatts)	Trigger ON Voltage	Protective Fuses
34312-1	1.0	0.10	390-410 VDC	1 x 3-2/10A Slow Blow
34312-2	1.8	0.18	390-410 VDC	2 x 3-2/10A Slow Blow
34312-3	2.6	0.26	390-410 VDC	3 x 3-2/10A Slow Blow

Alternatives to Shunt Regulators

➤ Additional Bus Capacitance

It is possible for some applications of the 230 volt series products that marginally require a shunt regulator to instead use additional bus capacitors to absorb the energy. If servodrive faults occur occasionally during some deceleration cycles, this may indicate that only a small amount of energy is tripping the drive, just enough to cause a problem sometimes. Experimentation is the best way to determine if additional capacitors will work in your application. For example, adding a 4000-7000 micro-farad capacitor to the bus just might do the trick.



Be careful, though! You'll need to use a capacitor with sufficient voltage for the servodrive. That means an electrolytic capacitor with a working voltage of no less than 450 VDC at 85°C ambient. Using a capacitor rated for anything less could cause irreversible damage to the servodrive and is a significant fire hazard.

Once a capacitor of sufficient voltage and capacitance has been obtained, simply connect the positive terminal of the capacitor to the "+" terminal of TB403 and the negative terminal of the capacitor to the "-" terminal of TB403.



WARNING! The capacitor terminals should be covered, preventing personnel from touching the dangerous voltages present when the servodrive is on and for several minutes after it has been turned off.

➤ Tying multiple servodrives together in multi-axis systems

If your system includes more than one axis, you're in luck! One way to avoid the added expense of shunt regulators is to connect the buses of each servodrive together as one. This is similar to adding bus capacitors with an added benefit: If one axis is decelerating (returning energy to the servodrives) while another axis is accelerating or driving the load (drawing energy from the servodrives), then the energy of the decelerating servodrive will be used by the accelerating servodrive.

Note that if this configuration is to be used, then input power **MUST** be applied to each servodrive simultaneously!



Make absolutely certain that the positive terminal of TB403 on each servodrive is connected together and the negative terminal on TB403 is connected to other negative terminals. Miswiring these terminals will cause irreversible damage to the servodrive.

Using a Shunt Regulator

There are two flying leads on the shunt regulator assembly. One wire is red and the other gray. The red wire is connected to the "+" terminal of TB403 and the gray wire is connected to the "-" terminal of TB403.



WARNING: Failure to connect the shunt regulator properly can cause irreversible damage to the servodrive and WILL VOID YOUR WARRANTY!



WARNING: High voltages are present on the shunt regulator module and TB403 on the servodrive when the servodrive is on and for several minutes after power has been removed. Appropriate precautions must be taken when working with or near the shunt regulator.

POSSIBLE SERVODRIVE CONFIGURATIONS

Due to the modular design of the SP series products, there are many possible servodrive configurations. This is particularly true in multi-axis applications using multiple SP series servodrives and servomotors.

The purpose of this section is to detail some of the servodrive configurations that may be useful in setting up your system.

Multi-axis System Sharing Power Supply

As discussed earlier in this chapter in the section on *Alternatives to Shunt Regulators*, many SP servodrive buses may be tied together in order to eliminate the need for a shunt regulator. In smaller SP20, SP30, SP50 and some SP75 multiple axis applications, it is possible to specify some servodrives with internal bus supplies and some without bus supplies. In this configuration, the servodrives without bus supplies get their bus from the TB403 connectors on the servodrives that have a bus supply.

Let's take a four (4) axis application, for example. Axis 1 is an SP75-2-B1-0 servodrive with a BR69-302000M servomotor. Axes 2 through 4 are SP20-2-C1-0 servodrives and BR13-402000M servomotors. The "C" in the SP20 part number indicates a *common bus* configuration and does not include AC rectifiers for AC input.

The *Shunt/DC Power* connector TB403 of axes 2 through 4 are tied together and connected to TB403 of axis 1. In this configuration, the bus power supply in axis 1 is supplying bus power to all axes in the system.

When evaluating such a configuration, consideration must be given to the power supply's rating. The following table offers some insight into the rating of the power supplies and the output power of each servodrive in the SP series. All specifications are based on three (3) phase, 240 VAC mains.

Servodrive and Motor	Power Supply Rating (kWatts)	Output Power (kWatts)
SP20-2-BX-X and BR13-402000M	4.2	0.81
SP30-2-BX-X and BR25-402000M	4.2	1.51
SP30-2-BX-X and BR34-362000M	4.2	1.76
SP50-2-BX-X and BR45-302000M	8.3	2.03
SP75-2-BX-X and BR69-302000M	8.3	3.12
SP75-2-BX-X and BR97-302000M	8.3	4.36
SP75-2-BX-X and BR115-242000M	8.3	3.81
SP100-2-BX-X and BR179-242000M	20	6.31
SP100-2-BX-X and BR238-242000M	20	8.30
SP100-2-BX-X and BR306-212000M	20	9.57
SP100-2-BX-X and BR344-242000M	20	11.31
SP150-2-BX-X and BR550-242000M	29	16.96
SP150-2-BX-X and BR757-242000M	29	22.42
SP150-2-BX-X and BR939-182000M	29	20.75

Using the table above and the example given above, you can see that the SP75-2-B1-0 and the BR69-302000M provides 8.3 kilowatts in the bus power supply. Of that, it consumes 3.12 kilowatts to drive the BR69-302000M servomotor if the motor is driven at its rating. The SP20-2-B1-0 and the BR13-402000M servomotors require 0.81 kilowatts each for a total of 2.43 kilowatts (3 axes X 0.81kW = 2.43kW). The total dissipation is, therefore, 2.43kW + 3.12kW = 5.55kW. This is well within the 8.3kW rating of the SP75-2-B1-0 power supply.

Sharing Shunt Regulators

Previously in this chapter, we demonstrated that it is possible to connect the bus connectors of servodrives together for multi-axis systems for the purpose of eliminating the need for a shunt regulator. In some multi-axis applications, however, this may not work due to the excessive energy returned during motor deceleration, or if multiple axes are decelerating simultaneously. The obvious solution is to put a shunt regulator on each axis that is faulting on BUS over-voltage. Another possibility is to tie all buses together and use one shunt regulator for all servodrives in the system.

When tying multiple axes together and using only one shunt regulator, you must consider the total energy returned to the servodrive. The application may call for two separate 100

Watt shunt regulators on two separate axes, or one 160 Watt shunt regulator tied to both axes.

Using the SP as a DC Servodrive

Personality modules are available for configuring the SP series servodrive for DC operation. DC operation is obtained by locking the commutation, using two of the three outputs to drive the DC motor, and electronically disabling the third output. The Peak and RMS ratings of the servodrive will be the same for the DC output as they are for the AC equivalent.

The command signal is applied single ended, or differentially to the Speed/Torque command pins 1 and 2 of the Input Commands Connector J1/P1. Factory configuration for the Speed/Torque command is for a single ended command to J1 pin 2, with J1 pin 1 grounded. (Refer to Input Command Signals and I/O for different signal input configurations). The external Tach is applied to the Tach Signal input J1/P1 pin 3, with respect to common, J1/P1 pin 4.

If field conversion of an existing SP servodrive is desired, the following procedure will configure the SP as a PWM DC servodrive using two of the three outputs.

1.	Obtain the proper personality module for your DC motor and load requirements. (Consult your Westamp representative).
2.	Remove the differential resistors from the control board (R172).
3.	Insure that the Hall pull-up resistor (R171) is installed on the control board.
4.	Place the servodrive in Six Step mode by moving the JP8 jumper on the control board to the Six Step position (pins 2 and 3).
5.	On the servodrive FeedBack Connector (J2), connect Hall "U" (J2-15) to digital ground (J2-3). No other connections are needed on the feedback connector. An encoder may be installed if an encoder derived tach signal is desirable.
6.	Connect the Motor Connector (TB402) as follows: Pin 1 Phase T Motor Terminal - Pin 2 Phase S Motor Terminal + Pin 3 Phase R No Connection Pin 4 GND Motor Case Ground.

7.	<p>If an external tachometer signal is required, remove the JP-12 jumper from the personality module. The external tach may now be applied between J1-3 (tachometer signal) and J1-4 (Signal Common) on the J-1 input commands connector. If the motor runs away, either the Tachometer or the motor leads (Phase S and T) may be reversed. Do not use phase R.</p> <p>If it is desirable to derive the tach signal from an encoder, the encoder lines should be attached to the J2 feedback connector and the JP-12 jumper should remain installed.</p>
8.	<p>If the opposite direction of rotation is required for a given polarity input command:</p> <p>1 - The Motor leads may be reversed (refer to step 8 for run away).</p> <p>2 - The Command inputs at J1-1 and J1-2 may be reversed. If a single ended input is used, this may require reconfiguring the JP1 jumper on the Personality Module. (Refer to Personality Module Connection Definitions and Specifications).</p>

Nominal configurations of a DC servodrive would be for a three phase input voltage of 115VAC, producing a DC bus voltage of approximately 160VDC. Care should be taken to insure that the three phase input voltage doesn't drop below 97VAC. Some earlier DC servodrive configurations required 70VAC input power. Although this was usually done to protect the servodrive, it is also possible that some earlier motors may have speed restrictions that could be exceeded because of the higher bus voltages on the SP. In these cases, the CMD and TACH pots should be adjusted to prevent an overspeed condition.

Using the New SP Servodrive in Place of the Earlier Version

The earlier version SP had a single row, 15 pin J1 INPUT COMMANDS Connector. The new version now has a dual row, 30 pin J1 COMMANDS connector. If the new SP is to replace the earlier model, the following steps must be performed.

➤ J2 Feedback Connector

Ensure the motor thermistor leads are wired from pin 1 (+5V) to pin 2 (N.C. input) of the J2 feedback connector.

If the motor temperature is being monitored elsewhere in the system, or if it is otherwise impossible to wire the thermistor leads to the J2 connector, JP3 on the personality module must be removed.



Note: Failure to monitor the motor temperature may void your warranty on the motor.

➤ J1 Commands Connector

More pins have been added to the J1 Commands Connector to increase functionality on the SP series servodrives. The additional functions include both normal and inverted outputs of the servodrive fault, motor temperature fault, encoder loss fault, and a drive ready signal. In addition, the new connector includes normally closed limit and disable inputs, and a jumper to shorten the startup / reset delay, if desired. If the new SP is replacing an earlier model, the following changes may be needed to the J1 connector:

- 1.) For the servodrive to operate, the normally closed limits and disable inputs (J1 pin 24, 25 and 26) must be returned to the common (J1 pin 27). Do not remove the factory installed jumpers from pin 24, 25, 26 and 27 of the J1 connector unless you are using these functions.
- 2.) Except for pin 8, pins 1 through 15 are the same for both versions of the SP. Connect any pins on your previous connector (except for pin 8) to the same pin on the new connector.
- 3.) Pin 8 on the J1 Commands Connector is now a disable input which will disable the servodrive when it is pulled to a logic low or shorted to ground. This pin will enable the servodrive immediately when it returns to a logic high or is removed from ground. If you are using pin 8 of the J1 Commands Connector for servodrive reset, it must be moved to the reset input pin 13. Pin 13 will provide the same delayed reset that was available on the previous SP servodrive.

GETTING STARTED


This section provides a step-by-step startup procedure. It is designed to give the user all of the necessary steps to commission an SP series servodrive. Each step in this section should be carefully read and completed.



WARNING: The following procedures detail working with the servodrive and its components. Many of the procedures include working with **LETHAL** voltages. These procedures should be carried out only by qualified engineers or technicians working with the appropriate test equipment. **PROPER PRECAUTIONS SHOULD BE TAKEN TO AVOID PERSONAL INJURY OR DEATH!**

Mounting Instructions

The first step is mounting your new servodrives in your enclosure. Please use the diagram and the table on the next page to determine the mounting dimensions.



Model Number	SP20 - SP75	SP100	SP150 - SP200
Dimension "A"	3.52	5.25	8.47
Dimension "B"	2.60	2.60	3.50
Dimension "C"	0.46	1.32	3.50
Dimension "D"	10.12	10.12	10.30

(All dimensions are in inches.)

Making Servodrive Connections

Input Power

Before connecting the power mains to the servodrive, ensure that the voltage and frequency are within the allowable range. The table below shows the allowable range for the 230V SP series servodrive.

Servodrive Series	AC Voltage Range min-max	Frequency (Hz) min-max
SP 20 to SP 100 230 volt products Mains and Control	97-265	47-63
SP 150 and above 230 Volt products Mains	97-265	47-63
SP150 and above 230V products Control Power	97-265	47-63


➤ SP20 to SP100, 230 Volt Product Input Power Connections

The SP20 to SP100, 230 volt SP series combines both the mains and the control power on one connector, TB401. Use the illustration on the following page to locate the connector.

Use the following table for main and control power connections for the SP 20 to SP100, 230V series:

	PIN 1	PIN 2	PIN 3	PIN 4
TB401	Phase A 97-265 VAC Line-Line	Phase B 97-265 VAC Line-Line	Phase C 97-265 VAC Line-Line	Earth Ground


Making Servodrive Connections



➤ SP150 and up, 230 Volt Product Input Power Connections

Power connections on the SP150 and above, 230 volt products differ slightly from the smaller series. On the SP20 to SP100, there is only one input power connector. This connector supplies power to both the control circuits and the bus power circuits.

Starting with the SP150 these functions are separated. The main three phase input power for the bus power circuit is connected on TB401, while the single phase input power for the control circuits is connected on TB404. Use the illustration below to locate these connectors.



Power Connections, SP150 and up

Use the following table for main and control power connections for the SP150 and above, 230V series:

	PIN 1	PIN 2	PIN 3	PIN 4
TB401	Phase A 97-265 VAC Line-Line	Phase B 97-265 VAC Line-Line	Phase C 97-265 VAC Line-Line	Earth Ground
TB404	97-265 VAC Line - Line single phase	98-265 VAC Line-Line single phase		

If desired, the control power may be obtained from the same source as the main power using only two of the phases.

➤ Single Phase Operation

For single phase operation, apply power to pins 1 and 3 on TB401. In addition, place a jumper from pin 1 or pin 3 to pin 2 of TB401.

Single phase AC operation requires special consideration to the single phase current capability of the servodrive, which is lower than the three phase current capability. Due to the differences in the power supply ampacities and the servodrive output power, this affects only some drives in the SP series. The table below details the effect of single phase operation for each drive and motor combination. Please note that the SP150 should not be configured for single phase operation.

Servodrive and Motor	Cont. Power Derating
SP20-2-BX-X and BR13-402000M	0
SP30-2-BX-X and BR25-402000M	0
SP30-2-BX-X and BR34-362000M	10%
SP50-2-BX-X and BR45-302000M	0
SP75-2-BX-X and BR69-302000M	24%
SP75-2-BX-X and BR97-302000M	45%
SP75-2-BX-X and BR115-242000M	38%
SP100-2-BX-X and BR179-242000M	0
SP100-2-BX-X and BR238-242000M	5%
SP100-2-BX-X and BR306-212000M	17%
SP100-2-BX-X and BR344-242000M	30%
SP150-2-BX-X and BR550-242000M	N/A*
SP150-2-BX-X and BR757-242000M	N/A*
SP150-2-BX-X and BR939-182000M	N/A*

*The SP150 MUST operate on three phase AC mains.

Input Power Filtering

Input power quality varies from site to site and from region to region. Westamp servodrives are designed to tolerate most transients and noise present on power mains. In certain applications, however, it may be necessary to use an input line filter.

➤ When You Need One

There are certain symptoms that indicate that an input power filter may be useful. If any of the following symptoms persist, then it may be necessary to install an input power filter:

- ⇒ Intermittent Bus or Bus/Phase faults
- ⇒ Positioning Module gains or loses position counts
- ⇒ Intermittent RMS faults when operating near zero speed
- ⇒ Positioning Module gets false I/O signals

Attacking the source of the noise or transient is the best way to prevent the problem from affecting other equipment, including the servodrive and motion controller. There are certain events on, around or near the machine to look for when searching for the source of power line transients and noise.

If any of the above symptoms occur, take note of what happened with other equipment or machinery on, around or near the machine just prior to or during the fault condition. For example, an AC motor starting or stopping, a clutch or brake firing, or power conductor opening or closing are excellent power line transient generators.

If the servodrive symptom can be tied to one of these events, then it may be possible to resolve the problem at the source. Usually, putting a Metal-Oxide Varistor "MOV" on the power line on or near the source will prevent any transients from transmitting all over the power lines.

➤ How to Specify an Input Power Filter

When specifying an input power filter, the most important factor is the rated voltage and current of the servodrive. Other factors, such as filter FCC and TUV classifications are important, but any input filter, irrespective of classification, will be significantly better than no input filter.

The voltage and current, however, are critical. Using the wrong voltage rating could cause a dangerous short to develop between the power lines or from the power line to the casing of the filter.



ONLY SPECIFY A FILTER THAT IS ENCLOSED IN A CONDUCTIVE METAL CASING. TO REDUCE THE HAZARD OF DEATH BY ELECTROCUTION, THE CASING MUST BE CONNECTED SECURELY TO EARTH GROUND!

➤ Minimum Filter Ratings

Use the table below to specify an input power filter's current ratings:

Servodrive and Motor	Minimum Filter Rating (amperes)*
SP20-2-BX-X and BR13-402000M	3
SP30-2-BX-X and BR25-402000M	5
SP30-2-BX-X and BR34-362000M	5
SP50-2-BX-X and BR45-302000M	6
SP75-2-BX-X and BR69-302000M	9
SP75-2-BX-X and BR97-302000M	12
SP75-2-BX-X and BR115-242000M	13
SP100-2-BX-X and BR179-242000M	19
SP100-2-BX-X and BR238-242000M	25
SP100-2-BX-X and BR306-212000M	25
SP100-2-BX-X and BR344-242000M	34
SP150-2-BX-X and BR550-242000M	50
SP150-2-BX-X and BR757-242000M	70
SP150-2-BX-X and BR939-182000M	70

* All current ratings are based on 3 phase input mains. For single phase filter ratings, multiply above ratings by 1.73.

Motor Feedback and Power Connections

➤ Motor Feedback/Power Connections for BR3 to BR8 Motors.

The Table below shows the pin relationship between the Motor Feedback and Power cable connector and the servodrive feedback and power connections for the Westamp Series BR3 to BR8 motors. Before the servodrive will function properly, the motor feedback signals and power connections must be properly connected. Most startup problems have to do with the feedback signals and power connections. The following table shows the pin to pin relationship between the motor connector and the servodrive feedback and power connectors:

Servodrive J2 Pin Number	Motor Pin Designator (P102)	Signal Description
1	E & S	+5 Volts (To Encoder and Thermal Switch)
2	R	Motor Thermal Switch
3	Cable Shield & T	Signal Shield and Encoder Common
4	W	Encoder Marker-
5	H	Encoder Marker +
6	U	Encoder Channel B-
7	F	Encoder Channel B+
8	V	Encoder Channel A-
9	G	Encoder Channel A+
10	M	Commutation Track Channel W-
11	Y	Commutation Track Channel W+
12	L	Commutation Track Channel V-
13	X	Commutation Track Channel V+
14	K	Commutation Track Channel U-
15	J	Commutation Track Channel U+
Servodrive TB402 Pin #	Motor Pin Designator (P102)	Description
1	C	Servodrive T Output
2	A	Servodrive S Output
3	B	Servodrive R Output
4	D	Servodrive Case and Cable Shield

Please use the drawing on the next page as an outline for the feedback.


➤ Motor Feedback Connections for BR13 to BR939 Motors

Before the servodrive will function properly, the motor feedback signals must be properly connected. Most startup problems have to do with the feedback signals. The following information shows the pin to pin relationship between the motor feedback connector and the servodrive feedback connector:

The table below applies to the Motor Feedback cable for Westamp BR series motors from BR13 to BR939.

Servodrive J2 Pin Number	Motor Pin Designator	Signal Description
1	K & L	+5 Volts (To Encoder and Thermal Switch)
2	A	Motor Thermal Switch
3	Cable Shield & T	Signal Shield and Encoder Common (Ground)
4	U	Encoder Marker-
5	M	Encoder Marker +
6	C	Encoder Channel B-
7	B	Encoder Channel B+
8	P	Encoder Channel A-
9	N	Encoder Channel A+
10	H	Commutation Track Channel W-
11	G	Commutation Track Channel W+
12	S	Commutation Track Channel V-
13	F	Commutation Track Channel V+
14	R	Commutation Track Channel U-
15	E	Commutation Track Channel U+

Please use the drawing on the following page as an outline for the feedback cable requirements.



For BR13 to BR939 motors - Feedback Cable Assembly

➤ Motor Power for the BR13 to BR939 Motors

The following table outlines the motor power cable connections to the servodrive for Westamp series motors from BR13 to BR939.

Servodrive TB402 Pin Number	Motor Pin Designator	Description
1	C	Servodrive T Output
2	A	Servodrive S Output
3	B	Servodrive R Output
4	D	Servodrive Case and Cable Shield

NOTE: SHIELD NOT APPLICABLE ON -3 ASSY.

BEND BRAIDED SHIELD BACK OVER THE JACKET & SOLDER TOUCH TO KEEP THE SHIELD TOGETHER

INSULATE CABLE & SHIELD WITH SHRINKING SLEEVING

#16 GA. GRN

STRIP & TIN WIRES .25"

STRIP & TIN .40", 4 PLCS

4.00"

.60"

1.09"

1.20"

DIM. "A" ±.00

GRN WHT RED BLK GRN

P103

JUMPER #16 GA. BUS WIRE

BR13 THRU BR104 -1 ASSEMBLY

GRN GRN WHT RED BLK

P103

BR115 THRU BR306 AND BR344 THRU BR939 -2 ASSEMBLY

SHIELD BLU WHT RED BLK

P103

BR1344 THRU BRH939 -5 ASSEMBLY

RECOMMENDED STEPS FOR ATTACHING GRAY WIRE TO SHIELD

1. SOLDER CABLE JACKET BY FORMING IN INCH OR MORE THE SOLID WIRE. (SEE FIG. 1)
2. FULLY INSULATE CABLE & SHIELD WITH SHRINKING SLEEVING.
3. FULLY INSULATE CABLE & SHIELD WITH SHRINKING SLEEVING.
4. PUSH RUBBER BUSHING BACK INTO HOUSING AND CLAMP IT.

FOR -5 ASSY. THE COLOR IS BLUE

RECOMMENDED STEPS:

△ SOLDER 1/4" OF GRN WIRE TO THE SHIELD. SEE RECOMMENDED STEPS.

△ LENGTH IS DETERMINED BY POWER CABLE MODEL NUMBER DEFINITION SHEET. SP-PC-1 LENGTH.

1. VIEW OF 1/4" OR 1/8" V/S. CONNECTORS ARE LOOKING INTO FRONT FACE OF PIN INSERT OR REAR OF SOCKET INSERT.

NOTES : UNLESS OTHERWISE SPECIFIED.

QTY	ITEM	DESCRIPTION	REMARKS
1	M83102A-32-17S	CONNECTOR	
1	M83106A-22-22S	CONNECTOR	
1	PT06E-14-5S(BR)	BUSHING	
1	M8342D-9	RUBBER (AMPHENOL 9779-513-B)	
AR	7L-0804AJ	CONDUCTOR (ANXITER)	8 AWG BLK/WHT/RED
AR	705-15	CONDUCTOR (STD WIRE)	8 AWG BLK/WHT/RED
AR	34349	(WESTAMP)	

QTY	ASST	ASSY	ASST	ASSY
-5	-3	-2	-1	-1

WESTAMP INC.
MOTOR CABLE ASSEMBLY

SP SERIES 34529

WESTAMP INC.
MOTOR CABLE ASSEMBLY

SP SERIES 34529

For BR13 to BR939 Motors - Power Cable Assembly


Input Command Signals and I/O

➤ Velocity Mode Configuration

To connect a command for velocity to the servodrive, first identify the type of signal to be applied: Single-ended or Differential. Single-ended inputs are usually referenced to the system common and are subject to common mode noise, i.e., noise that changes the reference or common level. Differential input is not referenced to common. Instead, it is referenced to another signal that is also applied to the servodrive.

Use the following procedure to configure the servodrive for a command for velocity:

- 1) If a positive signal from the command wire is to achieve a clockwise rotation of the motor (from the drive end of the motor), then:
 - A) If a Single-ended command is to be used:
 - 1) Connect the command wire to J1, pin 2
 - 2) Connect the reference wire to J1, pin 1.
 - B) If a Differential command is to be used:
 - 1) Connect the command+ wire to J1, pin2.
 - 2) Connect the command- wire to J1, pin 1.
 - C) Remove the Personality Module from the top of the servodrive by pulling up on the one or two locking tabs until they snap up about a 1/4 of an inch. Then remove the Personality Module by grasping the handle and slowly pulling it out of the servodrive. **DO NOT ATTEMPT TO PULL THE PERSONALITY MODULE OUT BY PULLING ON THE LOCKING TAB(S)!**
 - D) If a Single-ended command is to be used:
 - 1) Place the shorting plug on JP1 of the Personality Module between pins 1 & 2. Move ahead to step 3.
 - E) If a Differential command is to be used:
 - 1) Remove the shorting plug on JP1 of the Personality Module. Move ahead to step 3.



2) If a positive signal from the command wire is to achieve a counter-clockwise rotation of the motor (from the drive end of the motor), then:


A) If a Single-ended command is to be used:

- 1) Connect the command wire to J1, pin 1.
- 2) Connect the reference wire to J1, pin 2.

B) If a Differential command is to be used:

- 1) Connect the command- wire to J1, pin 2.

C) Remove the Personality Module from the top of the servodrive by pulling up on the locking tab(s) until they snap up about a 1/4 of an inch. Then remove the Personality Module by grasping the handle and slowly pulling it out of the servodrive. **DO NOT ATTEMPT TO PULL THE PERSONALITY MODULE OUT BY PULLING ON THE LOCKING TAB(S)!**



D) If a Single-ended command is to be used:


- 1) Place the shorting plug on JP1 of the Personality Module between pins 2 & 3. Move ahead to step 3.


E) If a Differential command is to be used:

- 1) Remove the shorting plug on JP1 of the Personality Module. Move ahead to step 3.

3) Remove the shorting plug at JP2.

NOTE: For safekeeping, place the shorting plug on only one pin of JP2 for possible use in the future.






4) Place a jumper plug at JP12:

5) Configure the Velocity Loop Integrator:

A) To select lowest value integrator (highest bandwidth), then place the shorting plug between pins 1 and 2 on JP11.

B) To select the highest value integrator (lowest bandwidth), then place the shorting plug between pins 2 and 3 on JP11.



NOTE: There will be further discussion on the integrator later in the chapter on Tuning.

C) Place the Personality Module back in the servodrive:

1) Slide the guide rails on the side of the Personality Module over both sides of the motherboard (back and front) until resistance is felt.

2) Push slightly harder until Personality Module is fully seated into connector. Usually, you will hear it snap into place.


3) Finally, push the locking tabs down until they are fully seated, locking the Personality Module into the servodrive.

The servodrive has been configured to accept a command for velocity!

➤ Torque Mode Configuration


A command for torque, also called a current command, configures the servodrive to convert the input signal into a command for current, not velocity. This mode is usually used with motion controllers that close the velocity loop in software.

Follow the steps in the previous section and the procedure below to configure the servodrive for a command for torque:




1) Remove the shorting plug at JP11.

A) For safekeeping, place the shorting plug on only one pin on JP11.



2) Place a shorting plug on JP2.



3) If use of the velocity signal developed by the servodrive and available on J1, pin 3 is not required then remove the shorting plug at JP12.

4) If use of the velocity signal is required, then turn the TACHometer potentiometer all the way counter-clockwise.

Making Positioning Module Connections

Feedback

➤ With a Westamp Positioning Module

If you are using an internal Westamp Positioning Module, refer to the Westamp manual for that Positioning Module.

➤ With an External Motion Controller

If use of an external motion controller is required in the application, then signal input, encoder feedback, fault data, and servodrive reset/disable connections to the motion controller should be made at J11. The output signals from the encoder are shared by both the servodrive and the motion controller in this configuration.

There are terminating resistors in resistor pack R172 within the servodrive. This may be changed to different values if needed. Usually, this is not necessary. But in cases where the cables are over 50 feet in length, these resistors may need to be changed to a higher value.

As a general rule, about 100 ohms per 20 feet of cable should be added. This will help keep the signal levels up while providing adequate termination impedance for noise suppression.

Some motion controllers include termination resistors, as well. Make certain that the use of termination resistors on both the servodrive and the motion controller does not exceed the output capability of the encoder or reduce the signal levels to unreliable levels.

Using an External Power Supply for the Encoder

In certain circumstances, it may be desirable to use a power supply for the encoders other than the servodrive's internally-developed 5 volt supply. This may be required because encoder power is needed even when the servodrive is turned off or due to noise generated by the servodrive that has become apparent on the servodrive's internally-developed 5 volt power source.

In either case, using an external 5 volt supply is easily accomplished by simply removing the wires on the feedback connector at J2 for +5 volts and Ground on pins 15 and 13, respectively, and connecting them to an external 5 volt source.

The external 5 volt source must be capable of supplying a minimum of 200 milliamperes of current and should be regulated to within $\pm 1\%$ of 5 volts.

Before Applying Power...

Initial Adjustments

This section describes the recommended initial potentiometer settings for "-A" personality modules. If you have "-B" personality modules then you may proceed to the next section.

"-A" personality modules are adjustable and provide potentiometers for the following functions:

CMD adjustment	CoMmanD signal input DC gain
Tach adjustment	TACHometer feedback DC gain
C-Comp adjustment	Coarse Compensation -- Velocity loop AC gain
F-Comp adjustment	Fine Compensation -- Velocity loop AC gain
I-Limit adjustment	Current Limit -- Clamps the peak output current of the servodrive
Offset	Nulls input offsets up to 50 millivolts

To minimize the risk of instability during the startup, it is suggested that the following settings are used:

CMD adjustment	20 Turns CCW, then 10 Turns CW
Tach adjustment	20 Turns CCW, then 10 Turns CW
C-Comp adjustment	DO NOT CHANGE FROM FACTORY SETTING
F-Comp adjustment	20 Turns CCW
I-Limit adjustment*	20 Turns CCW, then 3 Turns CW
Offset	20 Turns CCW, then 10 Turns CW

* NOTE: The I-Limit severely limits the peak current and should be slowly increased to its nominal value (usually fully clockwise) once proper operation is obtained.

Decouple the Motor

To minimize the risk of damage to the machine during the startup phase, decoupling of the motor and load is highly recommended. This will prevent a motor runaway from damaging the machine or injury to personnel.



If the system includes a personality module with an inertia mismatch specified in the personality module part number

then do **NOT** decouple the load from the motor and do **NOT** run the motor without the load connected. Running the motor without the inertia that is specified in the personality module part number may result in severe instability in the velocity loop and the motor may shake and vibrate violently.

Applying Power

As a final check before application of power, ensure that the voltage and frequency of the power lines are correct for the servodrive model.

Apply power to the servodrive and observe motor operation. If the motor moves quickly to a high speed or operates erratically, turn off the power and check power and feedback cabling (see Troubleshooting Guide).

If the motor moves slowly in one direction or the other, then turn the BALance potentiometer until the motor stops.

Moving the Motor

➤ With an Internal Positioning Module

If you are using an internal Westamp Positioning Module, refer to the Westamp manual for that Positioning Module.

➤ With an External Motion Controller

Enter a command to move the axis per the motion controller's instructions. If the motor runs away, then change either the polarity of the input signal to the servodrive or the encoder feedback signals between the servodrive and the motion controller.

To change the polarity of the input signal, see *Input Command Signals and I/O* in this manual. To change the encoder polarity switch the A and A Complement with the B and B Complement signals to the motion controller. NOTE: It is very important that the wiring from the encoder to the servodrive

remain in compliance with the drawings located in this manual. Any swapping of the A, A Compliment and B, B Compliment must take place between the servodrive and the motion controller!

If the motor moves under control, then phasing between the encoders and input command is correct. If the motor moves erratically or runs away, see the *Trouble Shooting Guide* in this manual.

If an external motion controller is used and the motor moves under control, but positive commands from the controller generate moves in a direction opposite the requirements of the application, then the feedback and command signals must be re-phased. This can be accomplished by switching the "A" and "B" encoder channels between the servodrive and the motion controller and switching the input command polarity. Remember, the encoder signals must NOT be swapped between the motor and the servodrive, so the above swap will have to take place between the servodrive and the motion controller.

TUNING

This section describes optimizing the servo loops through tuning. Many of the techniques described herein assume at least a basic knowledge of servo loop theory and application.

If the system appears stable and running, it may not be necessary to optimize the system by further tuning. Only in the most critical of applications where high hit rates are required with minimal settling time is it necessary to "critically dampen" the velocity and/or position loops.

Furthermore, if you have the "-B" Personality Modules, there are no potentiometers to adjust. These modules were designed to be critically damped with the customer-specified load information. If the system is not damped correctly using a "-B" module, see your sales representative, distributor or Westamp regarding different specifications for the module.

Note that if the system uses a "-B" module and has an inertia mismatch specified in the personality module part number, then the system may NOT appear stable without connecting the motor to the load considered when the inertia mismatch was specified.

With no Internal Positioning Module

This section will detail the procedures for tuning the velocity loop in the SP Series AC Brushless Servodrives when used as a stand alone servodrive or in conjunction with an external motion controller.

This section is intended for tuning adjustable personality modules (those with an "-A" suffix) only.


➤ Establishing a Good Feedback Loop

The first step in tuning the velocity loop is establishing the proper gain in the feedback or tachometer loop. The SP generates a velocity signal from the quadrature encoder output

signals using a high-performance Frequency-to-Voltage converter. The first pole of the F/V is at approximately 500kHz. The output of this circuit is very linear and responsive. There is no need for a DC tachometer.

Using an oscilloscope, observe the velocity signal response to a step input signal. The velocity signal can be observed at pin 3 of J1 with respect to pin 4 of J1. Identify which of the following illustrations best matches what is observed.


A




B



C



D



➤A - Overdamped

The overdamped illustration indicates that more velocity loop DC gain is needed. Increase the DC gain by turning the TACH potentiometer clockwise until a waveform like B or C is observed.

➤B - Critically Damped

The critically damped velocity loop illustrated in B is ideal and needs no further attention.

➤C - Underdamped

The underdamped illustration in C indicates that more bandwidth is needed in the velocity loop integrator or there is too much DC gain in the velocity loop. Try increasing the bandwidth by turning the F-Comp potentiometer clockwise.



CAUTION: This may cause instability in the loop!

Usually, you can use the F-Comp potentiometer to adjust out the undershoot that follows the first overshoot, but not the overshoot in its entirety. If an overshoot remains after the undershoot has been removed, it may be necessary to add some amount of derivative gain in the velocity feedback. A single overshoot, however, is not usually problematic in the position loop. If removal of the overshoot is required, then adding capacitance to C6 and R11 on the personality module may be required. Start with values of .01 microfarads for C6 and 10k ohms for R11, for example. Continue increasing the capacitance and decreasing the resistance until the overshoot is removed.

➤D - Unstable

Instability may be the result of a variety of system ailments, including low system natural resonant frequencies and poor tuning. In either case, the loop can usually be stabilized by reducing the gains, unless the natural resonant frequencies in the system are extremely low (<100 Hz).

It is suggested that you start by reducing the DC feedback gain or the TACHometer gain. This is done by turning the TACH potentiometer counter-clockwise.



NOTE: Turning the TACH potentiometer too far clockwise may result in motor runaway. Ensure that any hard machine limits are protected by the use of limit switches or soft stops. It is also advisable to reduce the peak current output of the servodrive by turning the I-Limit counter-clockwise 20 turns, then clockwise 2 to 3 turns.

SERVODRIVE CONNECTION DEFINITIONS AND SPECIFICATIONS

J1- Input / Output commands

Pin#	Function
1	<p>Speed/Torque / (Command Signal) Inverted Input - Used in conjunction with pin 2. This input is the negative input of the Command Signal input when connected differentially, or it may be configured as either the Non-Inverted Command Signal input return (common), or the Inverted Command Signal input when connected single-ended. The gain scaling for this input is achieved using the CMD potentiometer on the personality module. Turning the potentiometer clockwise will increase the Command Signal gain.</p> <p>Single-ended input: For single-ended input, the signal is applied to J1-1 with respect to common (J1-2 or J1-4). J1-2 must be tied to common for single-ended input by placing the shorting jumper JP-1, on the Personality Module, between pins 1 and 2 (the bottom two pins).</p> <p>Differential Input: For differential input, the signal is applied between J1 pin 1 and J1 pin 2. This pin(J1-1) becomes the negative input of the differential input command. To allow differential input, both J1 pins 1 and 2 must be ungrounded by removing the shorting jumper on JP-1 from the Personality Module.</p>
2	<p>Speed/Torque (Command Signal) Non-Inverted Input - Used in conjunction with pin 1, this input is the positive input of the Command Signal input when connected differentially, or either the Non-Inverted Command Signal input, or the Inverted Command Signal input return (common) when connected single-ended. The gain scaling for this input is achieved using the CMD potentiometer on the personality module. Turning the potentiometer clockwise increase the command signal gain non -Inverted Command Input:</p> <p>Single-ended Input: For single-ended input (Normal Westamp Configuration) the signal is applied to J1-2 with respect to common (J1-1 or J1-4). J1-1 must be tied to common for single-ended input by placing the shorting jumper JP-1, on the Personality Module, between pins 2 and 3 (the bottom two pins).</p> <p>Differential Input: For differential input the signal is applied between J1 pin 1 and J1 pin 2. This pin becomes the negative input of the differential input command. To allow differential input, Both J1 pins 1 and 2 must be unfounded by removing the shorting jumper on JP-1 from the Personality Module.</p>
3	<p>Tachometer reference signal output (not an input): Under Normal configuration, this signal is a reference indication of the electronically derived tachometer used by the SP servodrive. It is normally scaled to 1 volt / 1000 rpm for the SP series servodrives. This signal is internally generated. It may be used externally as a speed reference.</p> <p>Tachometer input signal: By removing the JP-12 jumper on the Personality Module, this pin becomes an external tachometer input. The gain scaling for this input is achieved using the TACH potentiometer. Turning the potentiometer clockwise increases the tach signal gain.</p>
4	<p>Signal Command Common - This is a signal ground that may be used to reference only command signal input related circuits. DO NOT USE THIS AS A CURRENT SINK FOR ANY OTHER CIRCUIT.</p>
5	<p>+5V - Up to 500ma is available for external use.</p>
6	<p>Negative Command Signal Input Limit / - - When this input is connected to J1 pin 11, or any other</p>

	<p>ground, or pulled to a CMOS logic low, all negative command inputs to the non-inverted input J1 pin 2, with respect to the inverted input J1 pin 1, are disabled. Internal pull-ups hold the normal condition of this input at a CMOS (12V) logic high.</p> <p>Note that this input disables all current in one direction only. The Drive Ready will remain asserted.</p>
7	<p>Positive Command Signal Input Limit /- When this input is connected to J1 pin 11, or any other ground, or pulled to a CMOS logic low, all positive command inputs to the non-inverted input J1 pin 2, with respect to the inverted input J1 pin 1, are disabled. Internal pull-ups hold the normal condition of this input at a CMOS (12V) logic high.</p> <p>Note that this input disables all current in one direction only. The Drive Ready will remain asserted.</p>
8	<p>Servodrive Disable Input./ - The signal present at this pin will be at +VCC (logical high) when the servodrive is operating normally, and at common (logical low) when the servodrive has disabled output as a result of a fault condition. Internal pull-ups hold the normal condition of this input as a CMOS (12V) logic high.</p> <p>Note that this input disables all output, and will place the servodrive in a "Not Ready" state when it is asserted (Drive Ready will go low, Drive Ready / will go high).</p>
9	<p>Fault output / (Latched output) - The signal at this pin will be at a 12V logic high under normal operation, and will go to common (logic low) when a fault condition occurs.</p>
10	<p>+VCC (+12VDC) - Up to 50ma is available for external use.</p>
11	<p>Logic Power Common.</p>
12	<p>-VCC (-12VDC) - Up to 10ma is available for external use.</p>
13	<p>Servodrive Fault Reset input - On the servodrive, a fault condition can be cleared by pulling this pin from its normal high (+12V) state to common or a logic low, then back to high. A half second delay will occur after this pin is allowed to go high, before the servodrive becomes enabled. Internal pull-ups hold the normal condition of this input at a CMOS (12V) logic high .</p>
14	<p>No Connection</p>
15	<p>Current monitor - This pin provides a voltage proportional to the output current command. It is scaled to +/- 10 volts = +/- full Peak output current of the servodrive. Its accuracy is +/- 10 % at full scale. Note that the signal is not the actual output current, but it is a command for current to the Current loops and is accurate unless the servodrive is saturated.</p>
16	<p>MTR Temp Fault Open Collector Output - (Latched Output) - The Latched output signal at this pin will be at a common (logic low) under normal operation, and will go to a CMOS logic high when a motor overtemperature condition occurs (The thermal switch within the motor opens). This requires that the motor's Normally Closed thermal switch be tied between pins 1 (+5V) and 2 (Motor Temp Input) of the J2 feedback connector. (see J2-Feedback Connector Definition and specifications). (cont.)</p> <p>If a servodrive fault/shutdown is NOT desired when a motor overtemperature condition occurs, the JP-3 jumper on the Personality Module must be installed. If the JP-3 Jumper is not installed, the MTR Temp Fault condition will disable the servodrive, creating a servodrive temperature fault.</p>
17	<p>MTR Temp Fault Open Collector Output / - (Latched Output) - The Latched Output signal at this pin will be at a CMOS logic high under normal operation, and will go to common (logic low) when a motor overtemperature condition occurs (The thermal switch within the motor opens). This requires that the motors Normally Closed thermal switch be tied between pins 1 (+5V) and 2 (Motor Temp Input) of the J2 feedback connector. (see J2-Feedback Connector Definition and specifications).</p> <p>If a servodrive fault/shutdown is NOT desired when a motor overtemperature condition occurs, the JP-3 jumper on the Personality Module must be installed. If the JP-3 Jumper is not installed, the MTR Temp Fault condition will disable the servodrive, creating a servodrive temperature fault.</p>
18	<p>Enc Fault Open Collector Output - (Latched Output) - The Latched output signal at this pin will be at a common (logic low) under normal operation, and will go to a CMOS logic high when a</p>

	<p>loss of one or more encoder signals at the J2 feedback connector occurs. (see J2-Feedback Connector Definition and Specifications).</p> <p>If a servodrive fault/shutdown is NOT desired when a Encoder Fault condition occurs, the JP-15 jumper on the Control Board must be installed. If the JP-15 Jumper is not installed, the Enc Fault condition will disable the servodrive, creating a combination of a servodrive logic and a servodrive temperature fault.</p>
19	<p>Enc Fault Open Collector Output / - (Latched Output) - The Latched Output signal at this pin will be at a CMOS logic high Under normal operation, and will go to common (logic low) when a Loss of one or more encoder signals at the J2 feedback connector occurs. (see J2-Feedback Connector Definition and Specifications).</p> <p>If a servodrive fault/shutdown is NOT desired when an Encoder Fault condition occurs, the JP-15 jumper on the control board must be installed. If the JP-15 Jumper is not installed, the Enc Fault condition will disable the servodrive, creating a combination of a servodrive logic and a servodrive temperature fault.</p>
20	<p>Fault Open Collector output - (Latched Output) - The Latched Output signal at this pin will be at a signal common (logic low) under normal operation, and will go to a CMOS logic high when a fault condition occurs.</p>
21	<p>Fault Open Collector output / - (Latched Output) - The Latched Output signal at this pin will be at a CMOS logic high under normal operation, and will go to common (logic low) when a fault condition occurs.</p>
22	<p>Drive Ready Open Collector Output - The signal at this pin will be at a signal common (logic low) when the servodrive output is disabled and will go to a CMOS logic high when the servodrive is operating. Note that when a Negative or Positive Limit occurs, which blocks output in one direction only, the servodrive will stay in the "Drive Ready" condition. (This pin will remain high).</p>
23	<p>Drive Ready Open Collector Output / - The signal at this pin will be at a CMOS logic high when the servodrive output is disabled and will go to a common (logic low) when the servodrive is operating. Note that when a Negative or Positive Limit occurs, which blocks output in one direction only, the servodrive will stay in the "Drive Ready" condition. (This pin will remain low).</p>
24	<p>N.C. Neg Limit Input - When this input is at a CMOS logic high, or allowed to float, all negative command inputs to the non-inverted input J1 pin 2, with respect to the inverted input J1 pin 1, are clamped. This input must be forced low for normal operation. Internal pull-ups will hold this pin at a CMOS (12V) logic high if it is allowed to float. Internal diodes allow for voltages of up to 40V to be applied to this pin when in its high state.</p> <p>Note that this input disables all current in one direction only. The Drive Ready will remain asserted (Drive Ready will remain high, Drive Ready / will remain low).</p>
25	<p>N.C. Pos Limit Input - When this input is at a CMOS logic high, or allowed to float, all positive command inputs to the non-inverted input J1 pin 2, with respect to the inverted input J1 pin 1, are clamped. This input must be forced low for normal operation. Internal pull-ups hold the normal condition of this input at a CMOS (12V) logic high if it is allowed to float. Internal diodes allow for voltages of up to 40V to be applied to this pin when in its high state.</p> <p>Note that this input disables all current in one direction only. The Drive Ready will remain asserted. (Drive Ready will remain high, Drive Ready / will remain low).</p>
26	<p>N.C. Disable Input - When this input is at a CMOS logic high, or allowed to float, all servodrive output will be disabled. This output must be forced low for normal operation. Internal pull-ups will hold this pin at a CMOS (12V) logic high if allowed to float. Internal diodes allow for voltages of up to 40V to be applied to this pin when in its high state.</p> <p>Note that this input disables all output, and will place the servodrive in a "Not Ready" state when it is asserted.</p>
27	Logic common -
28	No Connection
29	Fast Power-Up Input. (See pin 30 below)

30	Fast Power-Up Input. Without J1 pin 29 and 30 shorted together, the servodrive has a 1 to 2 second startup delay to allow motion controllers and other system components to stabilize. After the startup delay time, the Drive Ready signal will be asserted. When pins 29 and 30 are shorted together the startup delay is reduced to 100 to 200 milliseconds.
N O T E S	<p>The Open Collector CMOS Outputs have internal pull-up resistors to 12V, with blocking diodes. If higher voltage levels are required, an external pull-up resistor is needed. This output may be pulled up to 40VDC and source a current of 50 milliamps.</p> <p>The Latched outputs will permanently latch in the fault state if a momentary fault is sensed. The latched output will remain the fault condition even after the fault disappears. The Fault can be reset by removing and then reapplying logic power, or by creating a Reset. A Reset can be created by momentarily pulling J1-13 to a logic low, and then bringing it or allowing it to float high, or by pressing and releasing the reset button on the Fault Diagnostic Module.</p>

J2 -Feedback Connector

Pin#	Function
1	+5V - A maximum of 1V is available for external use
2	<p>Motor temp input- input pin for <u>normally closed</u> motor thermal switch (tied from this input pin to +5V). If this circuit is not being used, the JP-3 jumper on the Personality Module must be installed.</p> <p>The Motor Temperature Fault Normally Closed input (J2 pin 2) can be used with any normally closed contact, or logic input that will hold this input at a logic high. If this input is used for something other than the motor thermal switch, the motor temperature should be monitored elsewhere in the system.</p> <p>Note: Failure to monitor the motor temperature outputs or motor operation while the motor temperature rating has been exceeded could damage the motor and void your warranty.</p>
3	Signal Ground - use this pin as the ground for the encoder power and other digital signals.
4	Encoder "Z" / input - index or marker channel compliment input.
5	Encoder "Z" input - index or marker channel input.
6	Encoder "B" / input - Encoder data channel B compliment input.
7	Encoder "B" input - Encoder data channel B input.
8	Encoder "A" / input - Encoder data channel A compliment input.
9	Encoder "A" input - Encoder data channel A input.
10	Hall "W" / input - Hall W complement input.
11	Hall "W" input - Hall W input.
12	Hall "V" / input - Hall V complement input.
13	Hall "V" input - Hall V input.
14	Hall "U" / input - Hall U complement input.
15	Hall "U" input - Hall U input.

TB401 - AC Input Voltage

Pin #	Function
1	Phase "A" 97 - 265 VAC - Use this connector for 3 phase or single phase operation. For single phase operation Pin 2 should be externally tied to pin 1.
2	Phase "B" 97 - 265 VAC - Use this connector for 3 phase operation. For single phase operation this pin should be externally tied to pin 1.
3	Phase "C" 97 - 265 VAC - Use this connector for 3 phase or single phase operation.
4	Input Power Ground - Use this connector for the AC power input ground.

TB402 - Servodrive Output (Motor) Terminals

Pin #	Function
1	Motor Terminal "T" - When using Westamp cables, this is the Black wire.
2	Motor Terminal "S" - When using Westamp cables, this is the White wire.
3	Motor Terminal "R" - When using Westamp cables, this is the Red wire.
4	Motor Case Ground: - When using Westamp cables, this is the Green wire.

TB403 - Shunt / DC Power Terminals

Pin#	Function
1	Shunt / DC Power - (minus) - Negative DC bus. Use this connector for the negative side of the shunt regulator, if needed. On a multi-axis servodrive, this would be the negative bus output for a servodrive with internal bus, or a negative bus input for servodrives without a bus supply.
2	Shunt / DC Power + (plus) - Positive DC bus. Use this connector for the positive side of the shunt regulator, if needed. On a multi-axis servodrive, this would be the positive bus output for a servodrive with internal bus, or a positive bus input for servodrives without a bus supply.

TB404 - Control Input Voltage (SP150 and above)

Pin#	Function
1	97 - 265 VAC Control input voltage - input voltage source for control power on the SP150 and above.
2	97 - 265 VAC Control input voltage - input voltage source for control power on the SP150 and above.
	Note: The above two pins are internally isolated, and therefore polarity with respect to ground or phase is not required. If desired, the same power source used for TB401 can be used for the Control Input voltage.

J11 -Control I/O Connector

Pin#	Function
1	<p>Speed/Torque / (Command Signal) Inverted Input - Used in conjunction with pin 2. This input is the negative input of the Command signal input when connected differentially, or may be configured as either the Non-Inverted Command signal input return (common), or the Inverted Command Signal input when connected single-ended. The gain scaling for this input is achieved using the CMD potentiometer on the personality nodule. Turning the potentiometer clockwise will increase the command signal gain.</p> <p>Single-ended input: For single-ended input, the signal is applied to J1-1 with respect to common (J1-2 or J1-4). J1-2 must be tied to common for single-ended input by placing the shorting jumper JP-1, on the Personality Module, between pins 1 and 2 (the bottom two pins).</p> <p>Differential Input: For differential input, the signal is applied between J1 pin 1 and J1 pin 2. This pin (J1-1) becomes the negative input of the differential input command. To allow differential input, both J1 pins 1 and 2 must be ungrounded by removing the shorting jumper on JP-1 from the Personality Module.</p>
2	<p>Speed/Torque (Command Signal) Non-Inverted Input - Used in conjunction with pin 1, this input is the positive input of the command signal input when connected differentially, or either the Non-Inverted Command Signal Input, or the Inverted Command Signal Input return (common) when connected single-ended. The gain scaling for this input is achieved using the CMD potentiometer on the personality module. Turning the potentiometer clockwise increases the command signal gain for Non -Inverted Command Input:</p> <p>Single-ended Input: For single-ended input (Normal Westamp Configuration) the signal is applied to J1-2 with respect to common (J1-1 or J1-4). J1-1 must be tied to common for single-ended input by placing the shorting jumper JP-1, on the Personality Module, between pins 2 and 3 (the bottom two pins).</p> <p>Differential Input: For differential input, the signal is applied between J1 pin 1 and J1 pin 2. This pin becomes the input of the differential input command. To allow differential input, both J1 pins 1 and 2 must be ungrounded by removing the shorting jumper on JP-1 from the Personality Module.</p>
3	Signal Ground - use this pin as the ground for the encoder power and other digital signals.
4	Encoder “Z” / reference - index or marker channel compliment reference.
5	Encoder “Z” reference - index or marker channel reference.
6	Encoder “B” / reference - Encoder data channel B compliment reference.
7	Encoder “B” reference - Encoder data channel B reference.
8	Encoder “A” / reference - Encoder data channel A compliment reference.
9	Encoder “A” reference - Encoder data channel A reference.
10	<p>Servodrive Fault Reset input - On the SP servodrive, a fault condition can be cleared by setting this pin high, and then back to low. A half-second delay will occur after this pin is cycled back to low before the servodrive becomes enabled. Internal pull-up resistors hold this pin high.</p> <p>Servodrive Disable Input - During the time that this pin is high, the servodrive will be disabled. A half-second delay will occur after this pin is pulled low, resetting and enabling the servodrive.</p>
11	Drive Power On - This pin will be at a (12V) logic high when logic power has been applied to the servodrive.
12	Fault Bit 0 output - This signal is part of the four bit data word to indicate the status of the servodrive. Refer to the Fault Bit Status chart (next) for a description of this data word.

Pin#	Function
13	Fault Bit 1 output - This signal is part of the four bit data word to indicate the status of the servodrive. Refer to the Fault Bit Status chart (next) for a description of this data word.
14	Fault Bit 2 output - This signal is part of the four bit data word to indicate the status of the servodrive. Refer to the Fault Bit Status chart (next) for a description of this data word.
15	Fault Bit 3 output - This signal is part of the four bit data word to indicate the status of the servodrive. Refer to the Fault Bit Status chart (next) for a description of this data word.

J11 - Pins 12 to 15: Fault Bit Status Chart

MX_3	MX_2	MX_1	MX_0	Status
0	0	0	0	No Faults
0	0	0	1	RMS Fault
0	0	1	0	Surge Fault
0	0	1	1	Ground Fault
0	1	0	0	Logic Fault
0	1	0	1	Servodrive Temp Fault
0	1	1	0	Bus / Phase Fault
0	1	1	1	Motor Temp Fault
1	0	0	0	Encoder Fault
1	0	0	1	reserved
1	0	1	0	reserved
1	0	1	1	reserved
1	1	0	0	reserved
1	1	0	1	reserved
1	1	1	0	reserved
1	1	1	1	reserved

Note that the Fault Bit Output is a four bit data word. Along with the Power On output, this 4 bit word can be used to indicate the status of the servodrive. The output data is CMOS (12V) open collector with internal pull-ups. Because of the internal pull-ups, the No Fault State (0 0 0 0) will only be achieved when the servodrive is operating properly and all four lines are forced low.

CONNECTORS AND CONFIGURATION JUMPERS

Control Board Jumpers

Jumper#	Function
JP-14 JP-4 JP-5	<p>U Hall Differential / Single-ended Jumper. V Hall Differential / Single-ended Jumper. W Hall Differential / Single-ended Jumper.</p> <p>For use with differential input on the Halls (Normal Westamp operation), these jumpers are to be removed.</p> <p>If single-ended input is needed on the Halls, these three jumpers must be installed, and the differential load resistors must be removed from R172, pins 5-6, 7-8, 9-10. If pull-ups are needed for open collector single-ended Hall drivers, R171 may be installed (4.7 k ohms, parallel network resistors). For single-ended Hall operation, only the Hall inputs to the J2 connector, and not their compliments, will be used. (Refer to J2 Feedback).</p> <p>Differential input is the Normal Westamp Configuration. Due to the advantages of differential inputs, when connected to the outside world, it is recommended that whenever possible the differential inputs be used.</p>
JP-6 JP-7	<p>A Encoder Differential / Single-ended Jumper. B Encoder Differential / Single-ended Jumper.</p> <p>For use with differential input on the encoders (Normal Westamp operation) these jumpers are to be removed.</p> <p>If single-ended input is needed on the encoders, these two jumpers must be installed, and the differential load resistors must be removed from R172, pins 1-2, and 3-4. It is not recommended that open collector encoders be used. For single-ended encoder operation, the encoder inputs to the J2 connector, and not their compliments, will be used. (Refer to J2 Feedback).</p> <p>Differential input is the Normal Westamp Configuration. Due to the advantages of differential inputs when connected to the outside world, it is recommended that whenever possible the differential inputs be used.</p>
JP-8	<p>Sin / Six Jumper - For normal Sine Wave operation, this jumper is placed on positions 1 and 2. If Six-Step operation is desired, the jumper should be placed in positions 2 and 3. Westamp's Normal and recommended configuration is for the servodrive to be configured for Sine Wave Operation. (Jumper on pins 1 and 2).</p>
JP-14	<p>U Hall Differential / Single-ended Jumper. (see JP-4 and JP-5 above.)</p>
JP-15	<p>Encoder Fault Disable Jumper- If a servodrive fault/shutdown is NOT desired when an Enc Fault condition occurs, this jumper must be installed. With this jumper is installed, an Encoder Fault condition will be succeeded by the Enc Fault Out pins (J1-18 and J1-19), but it will not disable the servodrive. If the JP-15 jumper is not installed, the Enc Fault condition will disable the servodrive, creating a combination of a servodrive logic and a servodrive temperature fault.</p> <p>Normal Configuration is for the JP-15 jumper to be removed. (Encoder fault WILL cause a servodrive fault.)</p>

Personality Module Jumpers

Jumper#	Function
JP-1	<p>Differential / Single-ended Command Input Jumper - This jumper is used in conjunction with the J1 connector Signal inputs.</p> <p>For single-ended Non- Inverted Input : (Normal Configuration) The JP-1 shorting jumper is placed on positions 2 and 3 (bottom two pins).</p> <p>For single-ended Inverted Input : The JP-1 shorting jumper is placed on positions 1 and 2 (top two pins).</p> <p>For Differential Input : The JP-1 shorting jumper should be removed. Refer to the J1 connector for explanations on the signal input modes.</p>
JP-2	<p>High / Low Gain Jumper -</p> <p>For velocity control mode: Remove the JP-2 jumper.</p> <p>For torque (current) mode: Install the JP-2 jumper.</p> <p>Normal Westamp Configuration is velocity control mode (JP-2 removed).</p>
JP-3	<p>Motor Temp Fault Disable -If a servodrive fault/shutdown is NOT desired when a motor overtemperature condition occurs, the JP-3 jumper on the Personality Module must be installed. With this jumper is installed, a Motor Temperature Fault condition will be sensed by the MTR Temp Fault Out pins (J1-16 and J1-17), but will not disable the servodrive. If the JP-3 Jumper is not installed, the MTR Temp Fault condition will disable the servodrive, creating a servodrive temperature fault.</p> <p>Normal Westamp Configuration is JP-3 removed (Motor Temp Fault WILL cause a servodrive fault).</p>
JP-11	<p>Velocity Loop Integrator Jumper: -</p> <p>For highest bandwidth: (lowest value integrator) Install the JP-11 Jumper on pins 1 and 2.</p> <p>For lowest bandwidth: (highest value integrator) Install the JP-11 Jumper on pins 2 and 3.</p> <p>Normal Westamp Configuration is for lowest bandwidth (JP-11 on pins 2 and 3.) Refer to the chapter on Tuning for more information.</p>
JP-12	<p>Internal Tach Jumper. To use the internal electronically derived tachometer (Normal Westamp Configuration) the JP-12 jumper should be installed.</p> <p>If an external tach is used (refer to J1-3, Command Input connector), or if the servodrive is configured for torque (current) mode, the internal tach may be disabled by removing JP-12.</p>

TROUBLESHOOTING GUIDE

The maintenance procedures described in this manual should be attempted only by highly skilled technicians using proper test equipment. Before starting, read the warranty provisions to prevent voiding your warranty.

When any fault is detected by the servodrive, a qualified technician should determine that all external connections to the servodrive, all signals, and the load are in good working order. Failure to verify that the situation that caused the fault has been resolved before resetting the servodrive can permanently damage the servodrive, motors, and machinery, and may void your warranty!



Do not remove any connectors, jumpers, wires, etc., unless the POWER IS OFF!

Fault Indications

The table below describes some of the possible causes for LED fault indications:

LED	POSSIBLE CAUSES
(MTR) GROUND	1 - One or more output wires between the motor and the servodrive is shorted to ground. 2 - Breakdown in voltage (dielectric strength) in the output cables (shorted to ground). 3 - High parasitic capacitance in the output cables (particularly for long runs). 4 - Defective motor. 5 - Defective servodrive.
SURGE	1 - One or more output wires shorted together. 2 - Breakdown in voltage (dielectric strength) in the output cables (shorted together). 3 - High parasitic capacitance in the output cables (particularly for long runs). 4 - Defective motor. 5 - Defective servodrive.
RMS	1 - Excessive load current caused by mechanical binding or friction. 2 - Defective or miswired feedback cable. 3 - Defective or miswired power cable. 4 - Wrong Personality Module or EPROM installed for the motor being driven.
RMS (cont)	5 - Defective motor. 6 - Defective servodrive.

LED	POSSIBLE CAUSES
BUS/PHASE with Green power LED ON	<ul style="list-style-type: none"> 1 - Excessive regenerative energy from decelerating load. 2 - Defective shunt regulator or no shunt regulator installed.
BUS/ PHASE with green power LED OFF	<ul style="list-style-type: none"> 1 - One of the phases of the 3 phase AC input has failed. 2- Excessive noise on the AC input lines (see <i>Input Line Filters</i> in this manual). 3 - Defective servodrive.
TEMP	<ul style="list-style-type: none"> 1 - Excessive ambient temperature (servodrive is rated for 50 deg. C) 2 - Defective internal fan in servodrive. 3- Motor Over Temp. J-3 on the Personality Module must be removed to allow a motor overtemp to create a latched fault condition - See J2 -Feedback connector Motor Temp Fault and Personality Module jumper definitions (JP-3) and specifications.
LOGIC	<ul style="list-style-type: none"> 1 - Input voltage out of range (servodrive is rated for 97-265 VAC, 47-63Hz). 2 - Defective servodrive.
ENC FAULT	<p>Encoder Fault - Loss of an encoder signal. JP-15 on the control board must be removed to allow an Encoder Fault to create a latched fault condition. See J2-Feedback Connector Encoder Fault, and Control Board Jumpers definitions (JP-15) and specifications.</p>

Troubleshooting Procedures

This section provides additional details about troubleshooting the servodrive and its components. It is intended to assist the trained technician or engineer in identifying defective system components. It is NOT intended to assist in the repair of any failed components.

Symptom	Conditions	Possible Causes
No Output No fault lights	Input power LED NOT ON	Check three phase power input TB401 for proper AC input power. If single phase, insure that the single phase AC inputs are connected to TB401 pins 1, 3, and 4 (ground), and that pin 2 is jumpered to pin 1 or pin3.
	Input power LED ON	Insure that the motor feedback and armature cables are properly connected to the motor and servodrive.
		Check J1 for the following voltages: J1-5 = +5V J1-10 = +12V J1-12 = -12V And Check J2 for the following voltage: J2-1 = +5V If any voltages are missing, remove the J1 and J2 connectors, and after reapplying power, see if the voltages return. If they return, check for shorts in the cable/wiring.
		Check to insure that the servodrive is not being disabled from an external condition. J1 pin 8 and J1 pin 13 must not be pulled low, or output will be disabled. Also, J1 pin 26 must be pulled low (either by the factory installed jumper from J1 pin 26 to common, or by an external condition if the jumper is removed). Also, if J1 pin 24 is not pulled low, it will limit motion with negative input commands, and if J1 pin 25 is not pulled low, it will limit motion with positive input commands. Refer to Servodrive Connection Definitions & Specifications for J1 Connector.
		Disconnect the motor power connector and manually turn the motor while observing the incremental encoder signals: A encoder signal = J2 pins 8 and 9, B encoder signal = J2 pins 6 and 7. (Refer to the J2-Feedback connector description.) There should be a 90 degrees phase difference between the A and B encoder signals. The A NOT should be opposite the A (180 degree out of phase). Likewise, the B NOT should be opposite the B. If any of the above signals are missing, recheck the cables for proper wiring.
		Disconnect the motor power connector and manually turn the motor while observing the Hall signals at U Hall, (pins 15 and 14), V Hall (pins 13 and 12) and W Hall (pins 11 and 10). (See the J2-Feedback Connector definitions and specifications.) There should be 120 degree phase differences between the three Hall signals. The frequency of the Hall signals should be

Symptom	Conditions	Possible Causes
		3 HZ per motor revolution for a six pole motor, and 2 Hz per motor revolution for a four pole motor. If Differential Hall inputs are used, the Not (/) input should be opposite (180 degree out of phase) the logical input. (U NOT opposite U, V NOT opposite V, W NOT opposite W.)
		If the motor configuration being used is different than the factory defaults, insure that the Control Board jumpers are properly configured. Factory default settings are for Differential Inputs on both Hall and encoder inputs to the J2 Feedback connector. If a different configuration is used refer to the Control Board Jumpers chart under the Connectors and Configuration Jumpers section.
		Insure that the servodrive is receiving the proper signal command. The factory default settings for the input commands (J1 pins 1 and 2) are for single ended input to the - signal input (J1 pin 2), with the + signal input (J1 pin 1) tied to common. If differential input is desired, or if single ended input using the + signal input is desired, the JP1 jumper on the personality module must be changed. Refer to Connectors & Configuration Jumpers - Personality Module Jumpers for more information.
		Replace motor.
		Replace servodrive.
Erratic Movement motor jumps and kicks	No fault LEDs on	Insure that the motor feedback and armature cables are properly connected to the motor and servodrive.
		Check for loose or broken wires on the J2 Feedback connector
		Check and insure that the servodrive is properly grounded. The AC input voltage connector pin TB401 pin 4 should be tied to earth ground. The servodrive output (Motor Armature) terminal TB402 pin 4 should be tied to the motor case ground. (This is the green wire on the Westamp cable).
		It is recommended that shielded wire is used for the command signals and that differential input is used if your controller supports it. Terminate the shield for the encoder signals at the servodrive (feedback connector) end. Terminate the shield for the Command signals at the controller's end.
		Observe the incremental encoder signals: "A" channel encoder signals are present on J2 pins 8 and 9, "B" channel encoder signals are present on J2 pins 6 and 7. Refer to the J2 Feedback connector description. There should be a 90 degree phase shift between the A and B encoder signals. The A NOT should be opposite the A (180 degree out of phase). Likewise, the B NOT should be opposite the B.
		Observe the Hall signals on the J2 connector: U Hall = J2 pins 15 and 14, V Hall = J2 pins 13 and 12, W Hall = pins 11 and 10. (refer to the J2 Feedback connector description). There should be a 120 degree phase difference between the U, V, and W Hall (six step) signals. The U NOT Hall should be opposite the U Hall (180 degree out of phase). Likewise the V NOT and W NOT Hall should be opposite the V and W Hall respectively.

Symptom	Conditions	Possible Causes
		If any of the above signals are missing, recheck the cables for proper wiring.
		Disconnect the motor power connector and manually turn the motor while observing the Hall signals at U Hall, (pins 15 and 14), V Hall (pins 13 and 12) and W Hall (pins 11 and 10). (see the J2-Feedback connector definitions and specifications) There should be 120 degree phase differences between the three Hall signals. The frequency of the Hall signals should be 3 HZ per motor revolution for a six pole motor, and 2 Hz per motor revolution for a four pole motor. If Differential Hall inputs are used, the Not (/) input should be opposite (180 degree out of phase) the logical input. (U NOT opposite U, V NOT opposite V, W NOT opposite W)
		If the motor configuration being used is different than the factory defaults, insure that the Control Board jumpers are properly configured. Factory default settings are for Differential Inputs on both Hall and encoder inputs to the J2 Feedback connector. If a different configuration is used refer to the Control Board Jumpers chart under the Connectors and Configuration Jumpers section.
		Temporarily convert the servodrive to the six step mode by removing the left side cover and installing the control board's JP-8 jumper on pins 2 and 3. If the problem clears when the servodrive is in the six step position, the problem is in the encoder/feedback cable/circuitry. Re-inspect/repair the feedback cable. Substitute the motor if one is available. If additional noise immunity is required, an external logic supply may be used for the encoder feedback circuitry. (Refer to the procedure on <u>Using an External Power Supply for the Encoder</u>). Placing the servodrive in the six step position should be for troubleshooting only. In most circumstances, you will not want to leave the servodrive in six step mode. This will cause poor performance at lower speeds.
RMS Fault	RMS LED light is on.	An RMS fault indicates that the servodrive has supplied a current above the RMS rated current of the system for an extended period of time. The RMS fault occurs to protect the servodrive/motor and mechanical system.
		Insure that the load is not oversized. (The load is larger than the servodrive/motor combination can safely handle.)
		Insure that the motion profile does not have an extreme duty cycle. (The servodrive is pulling current above the RMS level for an excessive period of time.)
		Insure there is no binding or defective mechanical components causing an increase in machine friction. (The servodrive is requested to supply more than normal current because of a mechanical bind.
		The servodrive may not be properly compensated for the load. Recheck the Set - Up Procedure for the tach loop (refer to Set-Up Procedure in this manual).
		The motor could be defective. Replace the motor.
		Replace the servodrive.

Symptom	Conditions	Possible Causes
SURGE Fault	SURGE LED is on	Turn power off and disconnect the motor cable at the servodrive. (TB402 pins 1, 2, 3 and 4).
		If the SURGE fault light continues to illuminate after the motor cable has been disconnected at the servodrive end (TB402) and power reapplied, replace the servodrive.
		If the SURGE fault clears when the cable has been disconnected at the motor end (TB402) and power reapplied, reconnect the cable at the motor end and disconnect the motor armature cable at the motor connector.
		If the SURGE fault continues to illuminate after the motor cable has been disconnected at the motor end, the problem is probably the motor cable. Inspect and/or replace the motor cable.
		If the SURGE fault clears when the motor cable has been disconnected at the motor end, but illuminates when the cable is connected to the motor, there is an internal short in the motor. Replace the motor.
GROUND Fault	GROUND LED is on	Turn power off and disconnect the motor cable at the servodrive (TB402 pins 1, 2, 3 and 4).
		If the GROUND fault light continues to illuminate after the motor cable has been disconnected at the servodrive end (TB402) , and power reapplied, replace the servodrive.
		If the GROUND fault clears when the cable has been disconnected at the motor end (TB402) and power reapplied, reconnect the cable at the motor end, and disconnect the motor armature cable at the motor connector.
		If the GROUND fault continues to illuminate after the motor cable has been disconnected at the motor end, the problem is probably the motor cable. Inspect and/or replace the motor cable.
		If the GROUND fault clears when the motor cable has been disconnected at the motor end, but illuminates when the cable is connected to the motor, there is an grounded armature in the motor. Replace the motor.
LOGIC Fault	LOGIC fault LED is on	LOGIC fault indicates that the + 5V, -12V, or +12V logic voltage has dropped below the level required to reliably operate the logic circuits of the servodrive.
		Check J1 for the following voltages: J1-5 = +5V J1-10 = +12V J1-12 = -12V And check J2 for the following voltage: J2-1 = +5V If any voltages are missing remove the J1 and J2 connectors, and after reapplying power, see if the voltages return. If they return, check for shorts in the cable/wiring.
TEMP Fault	TEMP fault LED is on	A TEMP fault indicates that either the motor or the heat sink temperature (and thus the output transistor temperature) has risen beyond the safe operating range of the servodrive.
		Insure that the ambient temperature (the temperature directly outside of the servodrive) is below 50 degrees C. The drive is rated to pull RMS current at 50 degrees C. If the temperature

Symptom	Conditions	Possible Causes
		is above this, the ambient temperature must be lowered.
		If the servodrive uses a fan, insure that the fan is working properly.
		Insure that there is room to allow proper ventilation of the servodrive. Do not obstruct the intake or exhaust outlets near the top or the bottom of the servodrive. The module should be mounted vertically, so that air naturally passes through the heatsink from the bottom of the module to the top of the module.
		Insure that the motor temperature is not excessive. If the motor temperature becomes too high the internal thermal switch inside the motor will open, creating a temperature fault and disabling the servodrive. If a motor temperature fault has occurred, the Motor Temp Fault outputs at J1 pin 16 and J1 pin 17 will become asserted. Refer to the Servodrive Connection Definitions and Specifications for the J1-Input / Output commands.
BUS/PHASE Fault	BUS/PHASE LED is on	If a BUS overvoltage fault occurs when the servodrive is first turned on, check three phase power input TB401 for proper AC input voltage. Insure that there is power on all three phases. In-sure that the voltage is within the range listed for the servodrive.
		If the overvoltage fault occurs during a move, the system may be producing regenerative energy that is being returned to the servodrive. The fault circuitry may be protecting the servodrive by shutting it off to prevent higher regeneration.
		If there is no shunt regulator with the servodrive, it may be necessary to add one. If there is a shunt regulator, check to insure that the fuse has not blown.
Motor Slowly rotates With no input command	Controller position loop open or no position loop.	Insure that there is no input signal command at the J1 connector (J1-1 and J1-2). Adjust the offset pot (R23) on the Personality Module until the motor stops rotating.
Motor Runs Away	Controller Position loop may be opened or closed.	Check (preferably with an oscilloscope) the signal levels at J1-3, the Tachometer signal monitor, with respect to J1-4, the signal command common (Refer to the J1 connector description). This reference voltage should be proportional to the speed of the motor. (normally scaled to either 0.5V or 1V / 1000 rpm.) If there is no signal at this point insure that the JP-12 jumper is installed on the Personality Module. If there is a jumper on JP-12 inspect/repair the feedback connector as listed above.
		If there is a voltage at J1-3, insure that the Tach Pot (R12) on the Personality Module is not misadjusted. If the Tach Pot is turned too far counter-clockwise, the servodrive may loose tach feedback. Slowly turn the Tach Pot clockwise to see if the problem clears.
Motor Runs one direction only	No fault LEDs illuminated	Insure that the servodrive is receiving the proper command. Factory default settings require a positive input signal at J1 pin 2 with respect to J1 pin 1 for the motor to turn in a clockwise direction. A negative command will cause the motor to turn in a counter-clockwise direction. The command signal level and

Symptom	Conditions	Possible Causes
		<p>polarity may be checked at the J1 connector (J1 pin 1 and J1 pin2). Refer to the Servodrive Connection Definitions and Specifications for more information.</p>
		<p>Insure that the servodrive is not limited in one direction by an external condition. J1 pin 6 and J1 pin 7, the signal limit input / pins, must not be pulled low or the servodrive will be limited in one direction.</p> <p>Also: J1 pin 24 and J1 pin 25, the Normally Closed Limit inputs, must be tied to common, or pulled low or the servodrive will be limited in one direction. Refer to Servodrive Connection Definitions and Specifications for more information.</p>

DRAWINGS

This section includes all system drawings, such as schematics, assembly drawings and cable drawings.

SP20 Through SP100 Installation Drawing

DATE	LIT	REVISE TOP VIEW TO ADD J11/P1 CONNECTOR.	APPROVED	DATE
A	A			

**MOTOR ROTATION FOR ALL DATA CCW COUNTER CLOCKWISE
LOOKING AT THE FACE OF THE MOTOR.**

HALL INPUTS	A	B	C
MOTOR LEADS	R RESPECT TO S	S RESPECT TO T	T RESPECT TO R
MOTOR BEMF			
HALL SIGNALS			
	HALL "A" IS IN PHASE WITH STATOR "R" WITH RESPECT TO STATOR "S".	HALL "B" IS IN PHASE WITH STATOR "S" WITH RESPECT TO STATOR "T".	HALL "C" IS IN PHASE WITH STATOR "T" WITH RESPECT TO STATOR "R".

THE ABOVE SHOULD RESULT IN
 HALL "A" LEADING HALL "B"
 HALL "B" LEADING HALL "C"
 HALL "C" LEADING HALL "A".

ENCODER "A" AND ENCODER "B"	
ENCODER "A"	
ENCODER "B"	

* ENCODER "B" INPUTS LEADS ENCODER "A" INPUTS BY 90°. NOTE : ENCODER DATA CHANNELS NEED NOT BE ALIGNED TO ANY OTHER SIGNAL.

NORMAL CONFIGURATION, A POSITIVE (+) SIGNAL INPUT COMMAND AT J1-2 WITH RESPECT TO J1-1 SHOULD RESULT IN CCW MOTOR MOVEMENT AND PRODUCE A NEGATIVE (-) TACH REFERENCE VOLTAGE AT J1-3.


WAVE REPRESENTING STATOR OUTPUT

WAVE REPRESENTING HALL SENSOR

**VIEW A-A
ROTATED 90°**

CONTRACT NO. APPROVALS DRAWN BY: O. APPELH CHECKED BY: DATE: 12/19/94	TITLE MOTOR AND HALL POSITION CHART	WESTAMP INC. MOTOR AND HALL POSITION CHART
TO USE CONSUMER PROTECTED INFORMATION USE IN OTHER PRODUCTS IS PROHIBITED BY 15 USC § 2703.	SIZE C	DRAWING NO. 31923 A
PARTS LIST PART NO. QTY. UNIT 1000000000 1 ENCLOSURE	SP SERIES	REV. NONE PRINT TOP 1

Shunt / SP Installation




Personality Module Assembly

ZONE	DTR	REVISION	DESCRIPTION	APPROVED	DATE		

R5 R12 R14 R15 R28 R23 +
 +
 J6
 JP11 JP2
 LO
 JP1
 WHI
 JP3 ASSY 34540
 P12 JP12

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE	CONTRACT NO.	APPROVALS	DATE	WESTAMP INC.	PERSONALITY BOARD ASSEMBLY
FRACTIONS 9/16-4	DRAWN O. APPIAH	CHECKED MFG.	8-18-94	SP SERIES	DRAWING NO. 34540
DECIMALS XXX.XX	ENGR.	MATERIALS	FINISH	SIZE B	REV.
ANGLES XXX.X	DO NOT SCALE DRAWING	NEST/ASY	MED/ON	SCALE NONE	SHEET 1
TOLERANCES ARE	APPLICATION				


Fault/Diagnostic Board Schematic



WESTAMP INC. SCHEMATIC, DIAGNOSTIC INDICATOR BOARD		CONTRACT NO. APPROVAL DATE NAME: O. APPIAH DATE: 06-28-97 CHECKED: [] DESIGNED: [] DRAWN: []	REV: [] C SCALE: NONE 34732 SHEET OF 1
PART NUMBER: [] PART NAME: [] UNIT OR ASSEMBLY: [] APPLICATION: []		QUANTITY: [] MATERIALS: [] FINISH: [] DO NOT SCALE DIMENSIONS	MULTI

Fault/Diagnostic Board Assembly

REVISION			
ZONE	LTR	DESCRIPTION	DATE



UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE:		CONTRACT NO.		WESTAMP INC.	
FRACTIONS	DECIMALS	ANGLES	APPROVALS	DATE	
$\pm 1/64$	$.XX_{-} 01$	$\pm 2^{\circ}$	DRAWN O. APPLAH	6-30-97	
MATERIALS			CHECKED		
FINISH			MFG.		
DO NOT SCALE DRAWING			ENGR.		
NEXT ASSY	USED ON	MULTI		SIZE	REV.
APPLICATION				A	34735
			CODE IDENT NO.	DRAWING NO.	
			SCALE	NONE	SHEET 1 OF 1

For BR13 to BR939 Motors - Power Cable Assembly

NOTE: SHIELD NOT APPLICABLE ON -3 ASSY.

RECOMMENDED STEPS FOR ATTACHING GRAY WIRE TO SHIELD

1. SOLDER CABLE JACKET BY SOAKING IN TRICHLOROETHANE SOLVENT.
2. PULL JACKET BACK OVER CABLE & SOLDER WIRE TO SHIELD.
3. PULL JACKET OVER SOLDERED WIRE & SHIELD CONNECTION TO FULLY INSULATE TERMINATION.
4. PUSH RUBBER BUSHING BACK INTO HOUSING AND CLAMP IT.

QTY	QTY	QTY	ITEM	DESCRIPTION	REMARKS
1	1	-	MS3102A-32-17S	CONNECTOR	
-	-	1	MS3106A-22-22S	CONNECTOR	
-	-	1	PTD6E-14-5S(SR)	BUSHING	
1	1	1	MS3420-8	BUSHING	RUBBER (AMPHENOL 9779-513-8)
AR	-	-	7TL-0804AJ	CABLE	8 AWG 4 CONDUCTOR BLK, WHT, RED, BLU (ANIKTEER)
-	AR	-	705-15	CABLE	8 AWG 4 CONDUCTOR BLK, WHT, RED, GRN (STD WIRE)
-	AR	AR	34349		(WESTAMP)

PARTS LIST

QTY	QTY	QTY	ITEM	DESCRIPTION	REMARKS
-5	-3	-2	-1		
ASSY	ASSY	ASSY	ASSY		

RECOMMENDED STEPS:

△ SOLDER 1/4" OF GRAY WIRE TO THE SHIELD, SEE RECOMMENDED STEPS.

△ LENGTH IS DETERMINED BY POWER CABLE MODEL NUMBER DEFINITION SHEET, SP-PC-1 LENGTH.

1. VIEW OF "P" OR "MS" CONNECTORS ARE LOOKING INTO FRONT FACE OF PIN INSERT OR REAR OF SOCKET INSERT.

NOTES: UNLESS OTHERWISE SPECIFIED.

PART NO.	REV.	DATE	DESCRIPTION
34529	C	12/22/93	MOTOR CABLE ASSEMBLY


WESTAMP INC.

MOTOR CABLE ASSEMBLY

DRAWING NO. **34529**

SHEET **1** OF **1**

For BR13 to BR939 Motors - Motor Feedback w/Brake Cable



REV		DATE	APPROVED
A	OFFICIAL RELEASE	09-20-95	
B	ADD-5 CONFIGURATION		
C	PER E. O. 127005		

FOR PARTS LIST SEE BOM 34591 WITH APPROPRIATE DASH NUMBER	
UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES DIMENSIONS IN PARENTHESES ARE IN MILLIMETERS	
DESIGN: C. APPIAH	DATE: 02-02-95
CHK'D: B	SIZE: 34591
DRWN: C. APPIAH	DWG NO: 34591
SCALE: NONE	SP. SERIES: 3 OF 3
DESIGN: C	REV: C


RECOMMENDED STEPS FOR ATTACHING ALL SHIELDS & GRN WIRE TOGETHER

1. SOFTEN CABLE JACKET BY SOAKING IN TRICHLOROETHANE SOLVENT.
2. PULL JACKET BACK OVER CABLE & SOLDER ALL SHIELDS TOGETHER. SOLDER #16 GA. GREEN WIRE (2 LG.) TO THE SHIELDS.
3. PULL JACKET OVER SOLDERED WIRE & SHIELD CONNECTION TO FULLY INSULATE TERMINATION.
4. PUSH RUBBER BUSHING BACK INTO HOUSING AND CLAMP IT.

1. SOLDER 1/4" OF GRN WIRE TO THE SHIELD. SEE RECOMMENDED STEPS.
2. STRIP AND TIN ALL WIRES .25 MIN.
3. LENGTH IS DETERMINED BY FEEDBACK CABLE MODEL NUMBER DEFINITION SHEET. SP-FC-LENGTH.
1. VIEW OF "PT" OR "MS" CONNECTORS ARE LOOKING INTO FRONT FACE OF PIN INSERT OR REAR OF SOCKET INSERT. NOTES : UNLESS OTHERWISE SPECIFIED.

DETAIL A
BOTH ENDS

Bus Power Board Schematic




REV	DATE	BY	CHKD
A	2-25-94	H.M.	
B	12-12-95	R.S.	


REVISION	
DESCRIPTION	DATE
OFFICIAL RELEASE PER E. O. 115001	

CONTRACT NO.		WESTAMP INC.	
APPROVAL	DATE	SCHEMATIC, POWER BOARD	
BY O. APPIAH	04-17-95	SIZE	B
CHECKED		CODE	NONE
DRAWN		NAME	NONE
DATE		REV.	B
SCALE		QUANTITY	34522
MATERIALS		ISSUED OF 1	
FINISH			
APPROVED	DATE		
BY			
DATE			


Bus Power Board Assembly



Servodrive Control Board Schematic 1 of 2



Servodrive Control Board Schematic 2 of 2



Servodrive Control Board Assembly

