

**5x7 Status Display** After initialization, the ORION Status display will print the MotionBASIC® Version and installed MBX's. Once a user program starts execution, the display will be blank. When a user program terminates normally, the display will revert back to the Direct Mode starburst. If a user program terminates due to an error and enters direct mode, the program stopped led will be ON and the display shows the pertinent error code. Example: "E", "1", "8", "8", "5" ... for ERROR 1805 Program aborted.

**Status LEDs** when lit indicates the following:

- Watchdog OK ..... Green ..... Motherboard Processor is alive, flashes 1/sec.
- E-Stop OK ..... Green ..... 12 - 24 Volts is present at Terminal Block TB8 E-Stop.
- No-Fault ..... Green ..... The controller has no faults. FAULT@=0
- +24 VDC ..... Yellow ..... Power is present at TB8, +24 and referenced to RTN.
- MBX1 & MBX2 .. Yellow / Yellow .. MotionBASIC® Extensions, Under program control.
- User 1 / User 2 .... Yellow / Red ... User LED's indication, Under program control.
- MotionKEY Error ..... Red ..... MotionKEY is missing or insufficient credits.
- Program Stopped ..... Red ..... MotionBASIC® program not running. In Direct Mode.

**PC Card™ ATA** The required system card (right slot) can contain all the system executable programs, MotionBASIC® Extensions (MBX), user MotionBASIC® program, and data files. An optional PC Card™ (left slot) can be added for Ethernet communications or a Memory card for data storage. When the Green LED is ON or Flashing, it indicates that the controller is accessing the PC Card™.

**DO NOT REMOVE A PC CARD WHEN THE LED IS ON OR FLASHING.**

- FILES ... Display names of files currently stored on the booted SYSTEM Card™.
- MB Ver 4.x-5.x ..... MotionBASIC Versions have different drive names.
- FILES "D:\\*.\*" ..... Display files stored in root dir on RIGHT PC Card™.
- FILES "E:\\*.\*" ..... Display files stored in root dir on LEFT PC Card™.
- ..... MTP ..... .BAS ..... Filename extension (.ext) for below function.

**AUTOLOAD.ext** ..... File name which is designated to automatically load into the controller from the left PC Card™ on power up. Filename allowed in the left PC Card™ slot ONLY.  
**PB1LOAD.ext** ..... File loaded into the controller from the PC Card™ if the PB1 button is held pressed during power up. PB1LOAD.ext in the left PC Card™ will always OVERWRITE an existing PB1LOAD.ext on the System Card located in the right slot.

**Serial Ports** D=MotionDesk™ Development, 1= SRL1, 2= SRL2

**WARNING: DO NOT** connect the communications cable to J2 or J3 serial ports. This can cause damage to the ORION serial port or your computer port.

- Sending Serial ... Yellow .... Transmitting a character on serial port.
- Receiving Serial ... Yellow .... Receiving a character on serial port.
- OK to Transmit .... Green .... Handshake from other devices has been established.
- Ready to Receive ... Green .... Handshake from ORION.

**E-Stop** - (TB8 E-Stop) ORION controllers include an E-Stop monitor input, which is indicated by a green "E-Stop OK" LED above. For normal operation, Emergency Stop input power (+12 to +24VDC or 12 to 24VAC, referenced to TB8-RTN) is applied to TB8 E-Stop input. It is recommended that the input be interlocked with the servodrive main power auxiliary contact. Should that current be interrupted, the "E-Stop OK" LED will go off, causing a controller fault error. Error #1910: "E-Stop OK" Input Open.


**No Fault** - INTERLOCK (TB8 - No Fault, pins 4&5) ORION controllers have a "No Fault relay", located on the system module. This relay is an isolated "normally-open" output contact. As long as there are No Fault conditions in the controller (LED is ON), the relay will be energized, holding the output contact closed. The power to the No Fault relay is also hardware interlocked with both the E-Stop monitor input and Watchdog circuitry. It is recommended that the No Fault relay be interlocked in series with the main contactor coil. To reenergize this relay after a fault, "E-Stop OK" and "No Fault" LED's must be ON. The "No Fault" LED is only an indicator and tells you the contact SHOULD be closed.

**Reset** located on the system module is a reboot, like a PC key combination <Ctrl> <Alt> <Del>. Used to restart the system instead of flipping the power switch. Avoid turning the power on and off frequently.

**PB1 - Push Button one** can be used at power up (boot-up) in two ways:

**Inhibits** a MotionBASIC® program from running at boot-up.  
**Loads** a MotionBASIC® program. At power up, if PB1 is held in, the controller checks for one of the following program files in this order: PB1LOAD.ext on left slot PC Card first, System Card, right slot second. Filename extension (.ext) for MotionBASIC Ver 4.x or 5.x is (.MTP), MotionBASIC Ver 3.2 is (.BAS). PB1LOAD.ext on left PC Card will always OVERWRITE an existing PB1LOAD.ext on the System Card.


**ServoWire Axis Module (ORN-SW-AM) LED's** when lit, indicates the following:



- LED Name ..... color ..... Action
- DSP OK ..... Green ..... **Axis Module is operating properly.** No internal faults.
- MDATA ..... Green ..... Receiving MotionDATA communications.
- S-WIRE ..... Red ..... ServoWire Network configuration error.
- Examples: LED ON when two ServoWire Axis Module's are cabled together. Network connected in a ring. Too many drives on network.
- Axis A - H LED's are status indicators. Dual color, Green and Red.**
- The AXIS LED's, labeled A through H, are assigned in ascending order based on the drives ID's that are attached to the Axis Module ServoWire network. The lowest drive ID will be assigned to AXIS A LED. The next higher drive ID will be assigned to AXIS B and so on. Pacer and Virtual axes are also assigned a ServoWire AXIS Status LED.
- color(s) ..... Action
- Green ..... **Axis OK**, AFAULT@=0
- Red ..... **Axis fault**, see AFAULT@
- Red / Green .... Alternating (flashing) both Green and Red indicates mismatch in project vs Drive ID's setup.

**ORION ... Discrete Input / Output board**  
**Connecting External Field Power Supply at TB2**

The ORION model number indicates if it has an internal field power supply or not. The letter "F" = Internal Field supply, The letter "X" = NONE  
**WARNING:** If ORION has an internal 24VDC power supply, DO NOT connect another 24VDC supply to pins (+24, RTN) on TB2 or TB8



**Discrete I/O Point** - DIO@(number) ... number of the I/O point.  
 Read Input ..... PRINT DIO@(number) Zero=OFF, minus one (-1)=ON  
 Clear a Latched Input ..... DIO@(number)=OFF  
 Write Output ..... DIO@(number)=ON or OFF or Set time in milliseconds.  
 Configure I/O point ..... IO.MODE@(number)="letter"  
 letters are: I = Input, O = Output, (for any point)  
 R = Rising, F = Falling (Only the first 16 points)

**Trace Fuses** On the Discrete I/O board is a Fuse Test socket "F1" and spare holder. The below list of fuses are PRE-FUSED by the circuit board trace.  
**DO NOT USE A REPLACEMENT FUSE UNLESS THE TRACE IS OPENED!**  
 Discrete I/O board: ..... "F2" .... Extended Input /Output , +5VDC power.  
 System module trace fuses are located on the solder side (back) of board.  
 System module: "F1" ..... +5 VDC test at Interlock TB8 pin 7(+5) and pin 8 (R5)  
 System module: "F2" ..... E-Stop (12 to 24VAC)or(+12 to +24VDC) monitor voltage.  
 System module: "F3" ..... +24 VDC test at Interlock TB8 pin 1(+24) and pin 3 (RTN)  
 The replacement fuse is Wickman 250V, 4Amps. Part # 19370-062K